


ARG DUMP TRUCK>



BATTERY INSTALLATION:

- Open the battery compartment.
 Insert batteries into the correct + and polarities.
 Close the cover.



HOW TO USE:


- 1. Turn on the vehicle.
- 2. Move the control stick of the transmitter to pair to the vehicle.
- When the vehicle is functioning, that means pairing has been successful.
 If you have more than two vehicles, please pair one by one. When the second vehicle is pairing, please always keep the first vehicle and transmitter on.

 5. Please turn off both the vehicle and transmitter and re-start the pairing process if you are
- changing to play with another 2.4GHz transmitter.











PRODUCT MAY VARY SLIGHTLY FROM IMAGE SHOWN. PLEASE KEEP PACKAGING FOR FUTURE REFERENCE. PERFORMANCE TIPS: DO NOT DRIVE THE VEHICLE THROUGH WATER. DO NOT DRIVE THE VEHICLE INTO ANY HARD OBJECT.

WARNING: FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS, AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.

WARNING: THIS TOY PRODUCES FLASHES THAT MAY TRIGGER EPILEPSY IN SENSITISED INDIVIDUALS.

MARNING: CHOKING HAZARD-SMALL PARTS. NOT SUITABLE FOR CHILDREN UNDER 3 YEARS.





KEYCODE: 43334698

WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (* AND -), DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED, RECHARGEABLE BATTERIES ARE NOT TO BE CHARGED UNDER ADULT SUPERVISION. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOWNERN NOT IN USE FOR AN EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED, DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.