

anko

Coffee Maker

CM2101DE

USER MANUAL




IMPORTANT INSTRUCTIONS

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- For electrical safety, if the supply cord is damaged, it must be replaced by qualified electrical person only or the product must be disposed.
- This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farmhouses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
- The appliance must not be immersed.
- Do not place the appliance in a cabinet when in use.
- Heating element surface is subject to residual heat after use.
- Use the appliance according to this instruction, any misuse may cause electric shock or other hazards.

**PLEASE RETAIN THESE INSTRUCTIONS FOR
FUTURE REFERENCE**

-
- Regarding how to clean the surfaces that come in contact with food, please refer to the section with the heading <Cleaning >.
 - Before connecting the appliance, please check if the voltage indicated on the appliance corresponds with the main voltage in your home.
 - Do not place the appliance on a hot surface.
 - Do not use this appliance outdoors.
 - Remove the supply cord plug from the wall socket;
 - if problems occur during making coffee;
 - before cleaning the appliance.
 - Do not allow the main cord to come into contact with hot surface.
 - Use the appliance out of children reach. Prevent them from pulling the main cord.
 - Do pour any water before the appliance has been turned on.
 - To fill the water tank by fresh cold water only.

FEATURES OF COFFEE TO GO MAKER



Description

1. Travel mug 2. Lid 3. Top cover 4. Water tank 5. Base
6. Collecting tray 7. Switch

Before first use

For a perfect taste, carry out 2 or 3 boil-processes with fresh water (without coffee). Once all the water has passed through, switch off the appliance and let it cool down for 5 minutes. Then repeat the process with fresh water.

Making coffee

- Fill the water tank with the required quantity of water. Ensure that the water level is not higher than the “MAX” level mark. The “MAX” level mark is found on the water tank. Use fresh, cold water only.
- Fill the desired quantity of ground coffee into the filter.
- Place the mug on the collecting tray (without the lid on the mug).
- Switch ON the appliance. Wait until the brewing process is finished and the funnel has run empty.
- For each full cup: use approximately 20g of ground coffee.

Making more coffee straight away?

- If you have made one cup of coffee and wish to make some more straight away, please switch OFF the coffee maker and allow at least 5 minutes for it to cool down. Then you can refill the water tank.

Cleaning

- Always remove the supply cord plug from mains power outlet socket before cleaning the appliance.
- Never immerse the appliance in water.
- Clean it with a damp cloth.
- the filter and the funnel can be washed in hot soapy water.

Descaling

- Descale your coffee maker regularly.
- Fill the water tank with ordinary vinegar, below the Max. level mark found on water tank.
- Operate the appliance as described under the heading ‘Making

Coffee’ but without adding any ground coffee.

- After descaling let the appliance work twice more with only plain water to rinse away the remaining vinegar and any limescale.

TECHNICAL DATA

Voltage: 220-240V ~ 50-60Hz

Power: 600-700W

Water tank capacity: MAX 420mL

12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided.

This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty.

This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of

acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases	Contact for Target purchases
Kmart Australia Ltd. C/- Customer Service Centre 690 Springvale Road, Mulgrave Vic 3170 Customer Service: 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or via Customer Help at kmart.com.au	Target Australia Pty Ltd C/- Customer Service Centre 2 Kendall Street, Williams Landing, Vic, 3027 Customer Service: 1300 753 567 or via Customer Help at target.com.au/help/contact-us