

anko

**Toaster
LD-T7021B
User Manual**



**PLEASE READ AND SAVE THESE
INSTRUCTIONS FOR FUTURE REFERENCE**

IMPORTANT SAFEGUARDS

When using electrical appliance. Basic safety precautions should always be followed including the following:

1. Please read all instructions before operating and retain for future reference.
2. Make sure that your outlet voltage corresponds to the voltage stated on the rating label on the toaster.
3. Do not touch hot surface. Use handles or knobs only.
4. To protect against electrical shock, do not immerse cord, plug, or any part of the toaster in water or other liquid.
5. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning use of the appliance by a person responsible for their safety.
6. Children should be supervised to ensure that they do not play with the appliance.
7. Unplug unit from mains power outlet when not in use and before cleaning.
8. For electrical safety, if the supply cord is damaged, it must be replaced by qualified electrical person in order to avoid a hazard, or the product must be disposed.
9. Do not let the cord hang over edge of table or counter, or touch hot surfaces. Allow the appliance to cool before wrapping cord around base for storage.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Do not use the appliance for other than its intended use. Do not use outdoors.
12. Do not leave the appliance unattended when in use.
13. Do not use the toaster without the slide out crumb tray in place. The crumb tray should be cleaned regularly. Do not allow crumbs to build up in the tray.

IMPORTANT! Do not use this appliance with any food product containing sugar content or with products containing jam or preserves.

14. Oversize food, metal foil packages or utensils must not be inserted in the toaster as they may cause fire or electric shock.

CAUTION: The bread may burn, therefore toaster must not be used near or below curtains and other combustible materials. The toaster should be attended when in use.

15. The use of accessories or attachments not recommended by the appliance manufacturer may cause injuries.

WARNING! Electric Shock Hazard. Do not attempt to dislodge food when toaster is in use or connected to mains power.

16. Be sure to take the bread out carefully after toasting to avoid injuries from hot surfaces.

WARNING! When toasting small bread slices less than 85mm length, you must pay attention to the potential risk of burning when taking out the slices.

17. The appliance is not intended to be operated by means of an external timer or separate remote-control system.


18. Always unplug the appliance from mains power when not in use and before cleaning.

19. To disconnect, push the CANCEL button, then remove the power supply cord plug from mains power outlet socket.

20. If a slice of bread gets stuck inside the toaster, disconnect the toaster from mains power first and let it cool down before trying to remove the bread. DO NOT use a knife or a sharp tool, as these may cause damage to the heating element.

21. This appliance is intended to be used in household and similar applications such as:

- Staff kitchen areas in shops, offices and other working environments;
- Farm houses;
- By clients in hotels, motels and other residential type environments;
- Bed and breakfast type environments.

22.  Caution, hot surface. Care must be taken. The surfaces are liable to get hot during use.



23. When using this appliance, allow adequate air space above and on all sides for air circulation. Do not allow this appliance to touch curtains, wall coverings, clothing, dishtowels or other flammable materials during use. CAUTION is required when the toaster is placed on surfaces where heat may cause a problem, i.e. Laminated / Vinyl bench tops. Placing the toaster on an insulated heat pad is recommended to prevent heat damage to the surface.

WARNING!

Never operate toaster on its side. To prevent damage to the toaster, DO NOT toast with extremely runny ingredients such as butter, jam and other sugary ingredients. Adding any food substances to bread, muffins or crumpets can cause an electric shock and / or fire. This toaster is for toasting of bread, crumpets and muffins only.

**SAVE THESE INSTRUCTIONS
FOR HOUSEHOLD USE ONLY**

KNOW YOUR TOASTER



- | | |
|---------------------------------------|--------------------------------------|
| ❶ Bread toasting slots (Main chassis) | ❷ Push-down/Start lever (Main) |
| ❸ Selector (for toasting level) | ❹ REHEAT button + indicator light |
| ❺ CANCEL button + indicator light | ❻ DEFROST button + indicator light |
| ❼ Push-down/Start lever | ❼ Bread toasting slots (Sub-chassis) |
| ❽ Crumb tray | |

FOR THE FIRST USE

Manufacturing residue or oil remained in the toaster heating element may emit an odour when used for the first time, this is normal and will disappear after few minutes of use. When using for the first time, we suggest following the below steps under the heading USING YOUR TOASTER, except without bread. Then let the toaster cool down and begin toasting the first slice.

CAUTION: The bread may burn, therefore toaster must not be used near or below curtains and other combustible materials. The toaster should be attended when in use.

USING YOUR TOASTER

Important: Never let the toaster operate unattended.

Important: Do not operate the toaster without the crumb tray.

Important: Never use the appliance when it is empty (when there is no bread inside) except on first use.

Toasting

1. Unwind the power cable to the required length and plug it in.
2. Use the Selector (3) to set the required toasting level between 1 and 6. For a medium, golden brown, select level 3-4.
3. Place the food to be toasted in the Toasting slot (1).
4. Press the Push-down lever (2) down until it engages. The LED on the CANCEL button (5) will light up.
5. Toasting ends when the food being toasted is raised up. The LED on the CANCEL button (5) will go out.

Note: The toasting can be interrupted at any time by pressing the CANCEL button (5).

Tip: If you toast only one slice of bread, set the toasting level lower than you would normally use for two slices.

Tip: If you only toast one or two slices of bread at a time, put the bread in the Main chassis (1) and press the Push-down lever (2) to start toasting;

Tip: If you toast 3 or 4 slices of bread at a time, put the bread in the main chassis (1) and the Sub-chassis (8), press the Push-down lever (2) first, then press the second Push-down lever (7).

Reheating cold bread or toast

1. Insert the cold bread to be toasted
2. Press the Push-down lever (2) down until it engages. The LED on the CANCEL button (5) will light up.
3. Press the REHEAT button (4). The LED on the REHEAT button (4) will light up.

Toasting frozen bread

1. Select normal degree of toasting.
2. Insert the frozen bread to be toasted.
3. Press the Push-down lever (2) down until it engages. The LED on the CANCEL button (5) will light up.
4. Press the DEFROST button (6). The LED on the DEFROST button (6) will light up.

CAUTION

1. Remove all protective wrappings prior to toasting.
2. If toaster starts to smoke, press **CANCEL** to stop toasting immediately.
3. Avoid toasting the food with extremely runny ingredients such as butter, jam, etc.
4. Never attempt to remove bread jammed in the slots without unplugging the toaster from the mains electrical power outlet first. Be sure not to damage the internal mechanism or heating elements when removing bread.
5. The bread slot is for toasting regular bread slice.
6. To achieve uniform toast colour we recommend that you wait a minimum of 30s between each toasting time so that browning colour control can reset automatically.

CARE AND CLEANING

1. Before cleaning, disconnect the appliance from mains power outlet and let the appliance cool down completely.
2. Pull out crumb tray at the bottom of the toaster and empty it. If the toaster is used frequently, accumulated bread crumbs should be removed at least once a week. Make sure the crumb tray is completely closed before using the toaster again.
3. Wipe the outside of the toaster with a slightly dampened cloth and polish with a soft dry cloth.
4. Do not immerse the toaster in water or other liquids..
5. When not in use or during storage, the power cord may be wound under the bottom of toaster.

WARNING! Fire Hazard. The crumb tray should be cleaned regularly. Do not allow breadcrumbs to accumulate in the bottom of the toaster.

TECHNICAL DATA

Voltage : 220-240V~ 50-60Hz

Power : 1500 – 1800W

12 MONTH WARRANTY

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at Kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.