

LEAN AND GLIDE SCOOTER OWNERS MANUAL & ASSEMBLY INSTRUCTIONS



⚠ WARNING:

THIS MANUAL CONTAINS IMPORTANT SAFETY, ASSEMBLY AND MAINTENANCE INFORMATION. Keep this manual for future reference.

ASSEMBLY MUST BE COMPLETED BY AN ADULT. Obtain the required tools and then follow the assembly instructions in this manual. If you do not have the required tools, or have troubles understanding the instructions, we recommend that you seek assistance by an experienced bicycle mechanic.

FAILURE TO FOLLOW THESE INSTRUCTIONS MAY CAUSE SERIOUS INJURY.

SAFETY INFORMATION

⚠ WARNING:

- Always wear safety equipment such as helmet, knee pads and elbow pads.
- Always wear fully enclosed shoes.
- Do not use scooter at night.
- Do not use on wet surfaces, uneven or unpaved road.
- It is not recommended the scooter be used on steep slopes at high speed.
- Avoid sharp bumps, drainage grates and sudden surface changes.
- This scooter is not designed for off-road use or stunting.
- Never ride with more than one person on the scooter.
- Always follow local traffic laws.
- Always check the brakes before riding.
- Adult assembly required.
- Brake will get hot from continuous use, do not touch after braking.
- Read all information supplied by the manufacturer before riding.
- Recommended for children age: 3 years and up
- **THE MAXIMUM WEIGHT LIMIT FOR THIS SCOOTER IS 20 KGS/44LBS.**

FAILURE TO FOLLOW THESE INSTRUCTIONS MAY CAUSE SERIOUS INJURY

- Check and secure all fasteners before every ride.
- Ensure the clamp is locked correctly into position before every ride.
- **Wheel and Bearings:** Periodically check wheels and bearings for wear and tear and correct axle tightness.
- Replace worn and broken parts immediately.

Thanks for your purchase this product. If any parts are missing or damaged, please contact one of our Customer Service Representatives by phone on

1800-632-792 (Australia)

08 00623 792 (New Zealand)

via mail at spares@hunterleisure.com.au

Hyper Extension Pty, Ltd.

100 Keilor Park Drive Tullamarine, 3043, Victoria, Australia

ASSEMBLY INSTRUCTIONS

To safely assemble the scooter align the flat section of the handlebar stem with the corresponding fitting on the main scooter body and insert, depress the sprung button located on the stem and fully insert until you hear the button 'Click' in position. It's necessary that this locking device, has fully engaged before using the scooter, check the underside of the scooter and ensure the sprung button is protruding and correctly located and the handlebar is secure.

By depressing the sprung button the handlebar is easily removed from the scooter.



⚠ WARNING:

Failure to correctly install and tighten clamp may cause the rider to lose control and fall from the scooter. If you are unsure, please seek assistance by an experienced bicycle mechanic.

No modifications should be made to the scooter. The supplier will not be liable for any damage or injury that may occur with a modified product.

RIDING YOUR SCOOTER

1. Place one foot on the footboard of the scooter and use your other foot to propel the scooter.
2. To stop the scooter, apply the brake by stepping on the rear brake. We recommend that you practice applying the brake at various speeds and in an open area free from obstructions.

Leaning slightly left or right will turn the scooter in that direction.

⚠ WARNING:

The brake will get hot from continuous use. DO NOT TOUCH AFTER BRAKING.

MAINTENANCE

SCOOTER MAINTENANCE:

Properly maintaining your scooter will provide years of scooter-riding fun. To keep your scooter in good working order, do the following: Every time you ride, check and verify that the scooter is properly set up and locked. After riding, clean your scooter with a dry cloth to remove dirt and grime.

WEEKLY SERVICE:

(Must be performed by and Adult or under Adult supervision)

Apply a few drops of general purpose oil (available at your local hardware store) to the sides of each wheel axle. Verify that the axle screw are tight.