

anko

**Samosa Maker
TXW-028-1
User Manual**



PLEASE READ AND SAVE THESE
INSTRUCTIONS FOR FUTURE REFERENCE

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS

1. To protect against electric shock do not immerse the appliance, power cord, plugs in water or other liquids.
2. Close supervision is necessary when any appliance is used by or near children.
3. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
4. If the supply cord is damaged, it must be replaced by a qualified electrician to avoid a hazard, or the product must be disposed.
5. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries
6. The appliance is intended for household use only. Do not use outdoors or for commercial purpose. Any other use will void the warranty.
7. This appliance is intended to be used indoors in household and similar applications such as: staff kitchen areas in shops, offices and other working environments, farmhouses, by clients in hotels, motels and other residential type environments, bed and breakfast type environments.
8. Do not let cord hang over edge of table or counter or touch hot surfaces.
9. Do not place on or near a hot gas or electric burner, or in a heated oven.
10. Do not touch hot surfaces. Only use the handle provided.
11. Do not use appliance for other than intended use.
12. The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning use of the appliance by a person responsible for their safety.
13. Children should be supervised to ensure that they do not play with the appliance.
14. The appliances are not intended to be operated by means of an external timer or separate remote-control system
15. Do not use an extension cord with this appliance.
16. Always operate the appliance on an even surface. Make sure that there is enough ventilation, so that the hot steam can evaporate.
17. To avoid the danger of fire, never leave the appliance unattended. And never use appliance near any inflammable materials, such as curtains, wall cabinet...etc., due to risk of heat damage, burning and or fire.
18. Before connecting the appliance to mains power, the heating plates must be in closed position.
19. **Use only heat-proof synthetic or wooden utensils when removing food out of the samosa maker to prevent damage to the non-stick coating on the heating plates. Make sure that the utensils are not pointed or have sharp edges.**



Caution, hot surface. Care must be taken. The surfaces are liable to get hot during use.

20. For cleaning the cooking surface, please refer to section “Cleaning and Maintenance”.

**SAVE THESE INSTRUCTION
FOR HOUSEHOLD USE ONLY**

PARTS DESCRIPTION



Green light comes on when optimum temperature is reached

Red light comes on when connected to power source



Power indicator

BEFORE FIRST USE

The appliance has been packaged carefully to ensure the product is undamaged and in good condition after shipping. **DO NOT use if the product is damaged**, please contact Kmart for replacement.

Carefully unpack the appliance. Make sure not to discard any packaging material until all parts of the appliance have been found.

Carefully wipe the exterior of the appliance to remove any dust that may have accumulated during the manufacturing process. Dry with a dry towel. Do not use harsh abrasive cleaners.

IMPORTANT! Place the appliance on a flat, heat resistive surface only. To prevent heat damage to bench top surface, i.e. vinyl bench top, we recommend placing the appliance on a heat resistant mat to protect the bench top surface.

IMPORTANT! Before using the appliance for the first time, the cooking plates must be coated with cooking oil to protect the non-stick cooking surface.

OPERATION

1. Brush or wipe the toasting grids with a small amount of vegetable oil.
2. Preheat the appliance by closing the lid and plugging into an electrical power outlet.
3. When the power is ON **and** while the appliance is preheating, the **RED light will stay ON**. It will come **off** once the correct temperature is reached.
4. The appliance should preheat for a minimum of 2-3 minutes.
5. The grids will reach optimum temperature in approx. 5 minutes, then the **GREEN** ready light will illuminate to indicate ready state and the appliance will stop heating. The appliance will begin to reheat again when the **GREEN** ready light goes OFF. This cycle (the **GREEN** light switching ON/OFF) will continue to maintain the optimum heating temperature in the samosa maker.
6. Open the Samosa Maker and place pastry on the bottom baking plate.
7. Fill each compartment with appropriate amount of filling, pressing the bottom half into the plate to help even cooking.
8. Place the top sheet. Ensure it has fully covered the bottom sheet for a good seal.
9. Close the Samosa Maker.
10. **Do not force shut**. Steam may be released in between the cooking plates and care must be taken to ensure that fingers do not come into contact with the plates.
11. It will take approx. 3-8 minutes to cook depending on different fillings and your taste preference.
12. Open the Samosa Maker. Remove the samosa from the cooking plates using a plastic or wooden spatula. Never use metal knives as they may damage the non-stick coating.
13. Repeat the above operation if more samosas are needed.
14. Disconnect from mains power after use.

CAUTION:

1. During first use, the appliance may emit a small amount of smoke and/or odour due to lubrication burning off from the heating element. This is normal and harmless. Allow dry heating until smoke and odour no longer exists.
2. If too much mixture is inserted into the appliance, the samosa maker cannot be closed. Never close it with undue force as this could damage the appliance.
3. Never use sharp forks or knives to remove samosas as this would damage the non-stick coating on the baking surface. Use heat-resistant wood or plastic utensils only.
4. Always unplug the appliance from the power socket when not in use.

CLEANING AND MAINTENANCE

This appliance should be cleaned after every use.

ATTENTION: Make sure the appliance is unplugged from mains power and allow the appliance to cool down completely before cleaning.

CAUTION: Never immerse the Samosa Maker in water, other liquids or in a dishwasher!

1. Wipe the cooking surface with a soft damp cloth every time after use. If it is difficult to remove residues, use a little oil to soften it.
2. Do not use any spray-on cleaners or metal objects as they can damage the non-stick coating.

STORAGE

1. Unplug the Samosa Maker from mains power.
2. Allow the appliance to cool down completely.
3. Do not wrap the power cord around the appliance.
4. Store the appliance in a dry location and out of the reach of children.

TECHNICAL DATA

Voltage: 220-240V~ 50-60Hz

Power: 1400W

SUGGESTED RECIPE

Ingredients

For Pastry:

1 cup all-purpose flour

Water to Knead dough

2tbsp oil

¼ tsp salt

For Stuffing:

3-4 Potatoes (boiled, peeled & mashed)

1/2 cup Green Peas (boiled)

1-2 Green Chilies (finely chopped)

1/2tsp Ginger (crushed)

1tbsp coriander finely chopped

Few chopped Cashews (optional)

Few Raisins (optional)

1/2tsp Garam masala

Salt to taste

Red chili powder to taste

1/2 tsp. Dry Mango powder (optional)

Method

For Pastry:

Mix all the ingredients (flour, salt, oil) except water.

Add a little water at a time.

Pat and knead well for several times into a soft pliable dough.

Cover it with moist cloth and keep aside for 15 minutes.

For Stuffing:

In a bowl, add mashed potatoes, all dry ingredients (salt, chili powder, mango powder, garam masala), green chilies and ginger and mix well.

Add green peas, cashews and raisins and mix well.

Add coriander and keep aside.

Making Samosa:

Prepare the pastry cover on Samosa Maker as described on page 4 “OPERATION”.

12 Month Warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at Kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.