

12 month warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on **1800 124 125 (Australia)** or **0800 945 995 (New Zealand)** or alternatively, via Customer Help at **kmart.com.au** for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

Statement

- › High or low extreme temperatures that a battery cannot be subjected to during use, storage or transportation and low air pressure at high altitude.
- › Replacement of battery with an incorrect type that can defeat a safeguard
- › Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- › Leaving battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or of gas
- › A battery subjected to in an extremely low air pressure that can result in an explosion or the leakage of flammable liquid or of gas
- › CAUTION: Risk of explosion if the battery is replaced by an incorrect type

WARNING Do not dispose of unit in fire or water. › Never attempt to disassemble and reassemble. › Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. › Check with your local authority for recycle advice. › Keep your device and all accessories out of the reach of children and animals. › Small parts may cause choking or serious injury if swallowed. › Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C). › Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device. › Do not allow your device to get wet—liquids can cause serious damage. › Do not handle your device with wet hands.


Bluetooth® Headphones Operating instructions

includes:

- › True wireless earbuds
- › Charging cable
- › Use manual



Function overview:



How to use these earbuds:

Function Operation

Pause click **MFB button**

Play click **MFB button**

Next click either earbud **MFB button** twice

Previous click either earbud **MFB button** 3 times

Power ON / OF

Power ON

Option 1: Press and hold the MFB button 3s

Option 2: take the earbuds out of the charge case

Power OFF

Option 1: Press and hold the MFB button 5s

Option 2: put the earbuds back to the charge case

Earhook light on

If the earbuds in the charge case, take them out off the case the light will be on.

Earhook light mode

Press the light control button to change Light On, Flash and Off.

Pairing the earbuds with Bluetooth devices

› Once the earbuds is powered on, it is in pairing mode (LED flashes slowly) and will pair to the last paired device (if available).

› Pair the earbuds in Bluetooth menu in mobile phone and once it is paired, you can hear a pairing tone and the LED will off.

Bluetooth Name: KM43107261

Phone calls

› Press MFB button to pick up/hang up phone calls.

› press and hold the MFB button 1s to reject the calls.

Playing music

When the earbuds connects with the mobile phone via Bluetooth you can enjoy music through the headset wirelessly.

Battery Charging

This Bluetooth headset is powered by rechargeable Li-ion battery.

Please use the accessory USB cable to recharge the battery.

› Insert USB charging cable into a suitable USB port.

› Connect charging cable with the earbuds USB port .

› Earbuds indicator LED turns RED to show battery is charging. The indicator will off when fully charged.

› Charge case LED indicators will flash, when the charge case is charging. The LED indicators will steady when charge case fully charged.

› It takes earbuds about 2 hours to fully charge the battery.

› And it will take 3hours charge the charge case full.

Note

If the earbuds lost connect to each other, below 3 ways can resync them.

a.Put the earbuds back to the charge case, and then take them out.

b. Turn all earbuds off, and then turn on all earbuds.

c.In the shutdown status, press and hold the MFB button for 7 seconds, red and blue lights flash twice at the same time, turn off the earbuds and then turn on.

Specifications:

Model No:

43107261

Version:

V5.0

Support profiles:

A2DP, AVRCP, HFP

Working Distance:

10 meters

Music Time:

Up to 5 hours without earhook light, 3 hours with earhook light

Talk time:

Up to 5 hours without earhook light, 3 hours with earhook light

Standby time:

60 Hours

Charging voltage:

DC 5V

Charge time:

earbuds 2hours, charge box 3 hours

Cable length:

0.3m

Pairing window time:

3 minutes