封面

140 mm

105.001 mm

anko

Instruction Manual
K: 43-434-182 | 1-59-774-751
Model No. 333616

# Bluetooth LED Pixel Display

**IMPORTANT SAFETY INSTRUCTIONS.**
**The following safety precautions should always be followed, to reduce the risk of electric shock, personal injury or fire. It is important to read all of these instructions carefully before using the product, and to save them for future reference or new users.**

1. This product must only be used as intended in accordance with the enclosed operating instructions.
2. If the external flexible cable or cord of this luminaire is damaged, this product should be discarded.
3. If this luminaire stops unexpectedly or appears to malfunction, switch off the power supply and stop using immediately. Seek professional advice to rectify the fault or make repairs.
4. Switch off the power supply when not in use, before cleaning or changing accessories.
5. Keep the luminaire and cable away from sources of heat, sharp objects or anything that may cause damage.
6. We exert child some so there may become hot. Do not touch hot surfaces and supervise children around it.
7. This product has not been designed for use by children. Children should be closely supervised at all times when they are near any electrical appliance.
8. To protect against shock to shock, never allow the luminaire come into contact with water or any other liquid.
9. Never touch this luminaire liner has fallen into water. Do not in use until the product has been inspected and approved by a qualified electrician.
10. Do not use outdoors. This luminaire has been designed for domestic indoor use only.
11. Use only a microfiber cloth dry cloth for cleaning the product.
12. Do not use this product near inflammable materials, vapours or gases when operating it.
13. Do not leave the product in excessive heat, high temperatures can cause the product to malfunction.
14. The light source of this luminaire is not replaceable, when the light source reaches its end of life the whole luminaire shall be replaced.
15. Not suitable for mounting on tubular materials.
16. The product label located on back of the enclosure.

**Specification**
Rated power: 24 W
Number of the lamp beads: 256 pcs
Power supply method: 5V USB

**Function introduction:**

**Two ways to place:**
1. Desktop placement: take out the rod and insert the support rod hole, you can put it on the desk.
2. Wall placement: use specialized screws (not included) on the wall suggest screw head size 4-6mm,a pan length 20≥M3.5≤25 (Not Flat Jib Nail).

**Installation**
1. Connect the USB cable to a USB adapter (not included) with output voltage DC 5V 2a.
2. Scan the QR code below to download and install app with your mobile phone.

Voice code to download the app

or enter Google Play / Apple Store and search for "Colorlamp" to download.

3.Turn on mobile Bluetooth (connect to wait at this time)

4.Open "ZeeMatrix" app and connect to device

Notes:
A. When first time open the app,the pop up notice of whether to allow permissions,please select "allow".
B. Turn on Bluetooth and connect the device.
C. If no initial phone can't access the Bluetooth,please check to open the location.

5. Creative Outfits (each the outfits and you can DIY the picture by yourself)
The picture will be saved on "My material" Input ID on picture on "My material" and you will find it shows on the product screen




6. Creative animation: touch the animation and you can DIY the picture by yourself,several pictures combine into an animation, it will be saved on "My material",touch the animation on "My material",and you will find it shows on the product screen.

7. Text Editor: touch the text and you can DIY the content by yourself, it will be saved on "My material",Touch the icon on "my material" or click the existing number on the bottom,you will find it shows on the product screen.

**Embed - Due to screen limitations, only 2 letters can be displayed on the same time.**

8. How to check the alarm clock and you can set a date to check by yourself? It will alert you on time

9. Methods

a) Click the "+" on the APP, give a name and choose a picture and save.

b) Then click "⏰" to edit a schedule and save. Switch on if you need to use the schedule.

10. Stopwatch (count the total duration,it will don't counting on the product screen. Touch pause or reset button to stop or reset to start.

11. Countdown (set a time first,it will start countdown on the product screen. Touch pause or reset button to stop or reset the time.

12. Scoreboard: You can touch the "+" / "-" button to numerical counting.

13. Power: you can power-reader by adding the text/graffiti/animation on to easy play.

14. Preset Color: select the color effect you like and touch the "♡", it can be saved to "My material".

15. Preset Lamplight: choose the cold color you like and touch the "♡", it can be saved to "My material".

16. Preset light effect: choose the light effect you like and touch the "♡",it can be saved to "My material".

17. Modability materials: the designed and downloaded material save in "My material", you can click to share them on product scenes or make some changes by editing it.
Note: Material from Lamplight and Light effect can not edit or downloaded to device material.

18. Mixed Device: Users can select the material from "My material" or "Cloud material",combine into a colorful or moving 3 scroll in the "Overlay" button,it can be shared on the product screen. Nested Total 3 pages can be edited each time touch the "Overlay" button,it only can be shared 1 page in the last drawing.

19. Cloud material (animation&Picture): Select the picture or animation you like and download to "My material" or "Device Material",you can also do some changes by editing it.

20. Weather:
A.Select the mode: scene will vary and choose the light effect you like.
B.Touch the "Title" button and set the mobile phone or device city or your nearest county. Please select your county,allowing device near the product or mobile phone for better result.

21. Settings:

| Product type | Purchase date | Retailer/Online store | Item purchased | Reason for return | Desired refund amount | Replacement item wanted |
|---|---|---|---|---|---|---|
| Bluetooth LED Pixel Display | Date on your receipt (Must be within 30 days of purchase) | Where did you buy the item? (e.g. Kmart, Target, Amazon) | Did you purchase a gift card or digital code? (Yes/No) | Select one reason from the list and provide details if required | Do you want a refund to the original payment method? | Do you want an exchange for a different product? If so, which one? | Adjust, set up or brightness |

**Month Warranty**

**Thank you for your purchase.**

**Your new product it was tested to be free from defects in materials and workmanship for the period stated above from the date of purchase,provided that the product is used in accordance with accompanying recommendations or instructions where provided.This warranty is in addition to your rights under the Australian Consumer Law.**
For New Zealand customers,this warranty is in addition to statutory rights observed under the Consumer Guarantees Act.
We will provide you with your choice of a refund,equal battery provided,or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of returning the warranty.
This warranty will no longer apply where the this defect is a result of alteration, accident,misuse,abuse or neglect.
Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below. In the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.
Our goods come with guarantees that cannot be excluded under the Australian Consumer Law.You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

| Contact for Direct purchases | Contact for Target purchases |
|---|---|
| Kmart Australia Ltd<br>(1) Customer Service Centre<br>690 Springvale Road,<br>Mulgrave Vic 3170<br>Customer Service:1300 1203 23<br>Business Enquiries:(03) 562 1805<br>Store Locator:kmart.com.au<br>Customer Help:au.kmart.com.au | Target Australia Pty Ltd<br>(1) Customer Service Centre<br>7-11 Talavera Road, Macquarie Park,<br>NSW 2113<br>Customer Service:1300 753 567<br>Or via Customer Help at:<br>target.com.au/help?contact=cc |