INTERACTIVE WATCH
- USER GUIDE -

TABLE OF CONTENTS

1) POWER ON/OFF
2) CLOCK FACES
3) STATUS BAR ICONS
4) BATTERY RECHARGING
5) SPLASH PROOF
2) GAMES
3) CAMERA
4) VIDEO
5) PEDOMETER
6) ALBUM VIEWER
7) TIME TOOLS
7.1) ALARM
7.2) STOPWATCH
7.3) TIMER
8) VOICE RECORDER
9) CALCULATOR
10) SETTINGS
11) VOICE RECORDER
11.2) DATE
11.3) TIME
11.4) STORAGE
12.5) BRIGHTNESS
12.6) VOLUME
12.7) DEVICE RESET

1) Power On and Power Off:
- Power on: Press and hold the power button to turn on the watch.
- Power off: Press and hold the power button to turn off the watch.
- Home menu: Press the power button once to display the clock.

2) Clock Face:
- Press and hold the center of the clock to change the clock face.

*swipe in any direction from the clock face to proceed to the main menu.

3) Status bar icons:

4) Battery Recharging:
*Note: Adult supervision is suggested.

- Gently pull out the cover of the Micro-USB port on the right side of the watch.
- Insert the included Micro-USB cable (small end) into the Micro-USB port on the watch.
- Insert the large end of the Micro-USB cable on your computer or to the included USB charger.
- Once the connection is successful, you will see a battery-charging symbol appear on the watch screen.
- When the battery is fully charged, the charging icon will stop animating and the battery symbol on the screen will show full.
- When the battery is fully charged, disconnect the charger from the power outlet first, then disconnect the watch from the charger cable.
- The battery strength icon on the status bar will scroll until the device is fully charged.

Note: Please charge your watch before you use it. It takes approximately 1 hour to fully charge the battery.

Battery Warnings:
Misuse of batteries can lead to them bursting, causing a fire or chemical burns. Please read the following precautions:

- Do not disassemble the battery.
- Do not crush and do not expose the battery to any shock or force such as hammering, dropping, or stepping on it.
- Do not expose to high temperatures or place near a heat source.
- Do not leave in direct sunlight.
- Do not dispose of in a fire.
- Do not handle damaged or leaking batteries.
- Keep the battery out of the reach children.
- Keep the battery dry.

5) Splash Proof for Everyday Play:
- Do not put the watch under running water.
- Do not submerge under water. Not suitable for showering, bathing, or swimming.
- Keep the cover of the Micro-USB port closed tightly while it is not in use in order to prevent any water getting in the watch.

2) Games:

- NUMBER GRID
- FIGHTER PILOT
- MEMORY
-CAN CHAOS
-STONE WAR
-SNAKE IN THE GRASS

3) Camera:

- Tap the camera icon in the main menu to enter camera mode.
- Tap the shutter icon to take a photo.

- Tap the save or trash bin icon to save or delete your last photo.

4) Video:

- Tap the video icon in the main menu to enter video mode.
- Tap the record icon to begin recording video.

- When you are finished, tap the same icon.
- Tap the save icon to save your last video.

5) Pedometer:

*The S-Watch pedometer is count your movements. The watch should be worn on the wrist for accurate measurement.
- Tap the start icon to start the pedometer and you can tap the stop icon to stop it from counting any further.
- Tap the reset icon to reset the counter back to zero.
- On the pedometer screen you can check the distance walked and calories burned.

* This pedometer is just for fun and is not 100% accurate. The pedometer only measures steps taken while the watch is moving. It does not measure steps taken while you are driving or on an escalator. If it is worn on the arm that is moving. Swipe right screen to exit the main menu.

4) Album Viewer:
- Tap the album viewer icon on the main menu to browse or delete your photos and videos.

7) Time Tools:

7.1) Alarm:

*swipe right to exit to the main menu.

- Select the hour and minute by tapping up or down on the hours, minutes and AM/PM.

- Tap the tone icon to display the alarm tone selection menu. There are 4 build-in alarm sounds, tap left or right to preview and select one of the three different tones.

- Once you choose an alarm, tap the green check icon to confirm and start your alarm.

7.2) Stopwatch:

*swipe right to exit to the main menu.

- Tap the play icon to start your stopwatch.

- While the stopwatch is running, tap the pause icon to pause the stopwatch. Tap it again to resume.

- Tap the reset icon to stop the stopwatch and reset the time back to zero.

7.3) Timer:

*swipe right to exit to the main menu.

- Tap the timer to enter timer settings.
- Tap the play icon to start the timer immediately. Tap up or down on the minutes and seconds to change the time. Once set, tap the green check to confirm.

- While the time is running, tap the pause icon to pause the countdown and tap it again to resume. Tap the reset icon to stop the countdown and reset the timer.

8) Voice Recorder:

*swipe right to exit to the main menu.

- Tap the record icon to start recording, when you finish recording, tap it again to stop.

- Tap left or right to review the previous or next recording.
- Tap the play icon to display and play back your last recording.
- To delete a recording, tap the trash bin icon to delete.

9) Calculator:

*swipe right to exit to the main menu.

- Tap the calculator icon to enter the calculator function.
- Tap the "C" button to clear the calculator.
- Tap the button to delete the last number typed.

10) Settings:

*Tap left or right to scroll through the setting options.

10.1) Wallpaper: Tap the "set" button to choose one of three wallpapers to select.

10.2) Date: Tap up or down on the month, day and year to set the date. Tap the green check icon to save.

10.3) Time: Tap up or down on the hours, minutes and AM/PM to set the time. Tap the green check icon to save.

10.4) Storage:
* An 8GB SD card is recommended for adding micro SD storage to this device in a dry and safe environment. To remove screws on the case back, use a micro or eyeglass screw driver. Expandable up to 32GB

- Tap the "set" button to enter the storage menu.

- Tap "watch" to save photo, video, and voice recordings to the watch.
- Tap "card" to save photo, video, and voice recordings to the memory card if one has been added.
- Tap "space" to view the space remaining in both the watch storage and micro SD storage.

10.5) Brightness: Tap the + or - icons to set the screen brightness.

10.4) Volume: Tap the + or - icons to set the system volume.

10.7) Device Reset: Tap the "set" button to reset the watch to its factory settings. Once prompted, type password "1122" and the watch will restart and reset.

⚠ WARNING
CHOKING HAZARD
Small Parts. Not for children under 3 years.

Distributed by:
Time Interactive Ltd
Unit 402, 4/F., Grand Trend Building,
31 Heung Yip Road, Wong Chuk Hang,
www.timeinter.net

Questions or comments, please email: cs@timeinter.net
WEEE-(2012/19/EU) Do Not Dispose Watch Only
Via Municipal Waste Collection
Part Text: 47.1098

Made in China

LIMITED WARRANTY:

The product you have purchased is covered by a warranty in the terms below. This warranty is provided by Techmedia International Limited (herein "Techmedia"). The warranty applies for a period of 12 months from the date of purchase.
Techmedia warrants that the product will be substantially free from defects for the warranty period. Techmedia will, at its option, repair or replace the product at no charge, provided that the defective repair, replace or provide credit in respect of goods that are defective in the warranty period.
This warranty covers only guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if goods fail to be of acceptable quality and the failure does not amount to a major failure.
The term 'Major Failure' is defined in the Australian Consumer Law and includes but is not limited to goods that are unsafe, unusable, or goods that are substantially different from the description supplied and cannot easily and within a reasonable time be remedied to make them fit for such a purpose.
where the goods are unsafe.
The benefits provided by this warranty are in addition to any other rights and remedies of the consumer under any law in relation to the goods or service to which the warranty relates.
Exclusions
The warranty does not cover defects or problems that arise due to you causing the product to operate outside its intended uses, or due to any unauthorised modification of the product or damage caused by abnormal use of the product. To the extent permissible at law, it does not cover damage caused by accident, misuse, abuse, neglect, alteration, improper installation, or repair carried out by authorised repairers, or by your use of the product contrary to any usage recommendations or instructions.
Further, the warranty does not cover defects where you were informed of the issue before agreeing to acquire the goods or you examined the goods before accepting them and that examination revealed the defect that would have been found.
Claiming Warranty
For the warranty to be honoured you must submit the fault or product, together with proof of purchase to the original place of purchase or send them to Warranty Claims, Techmedia International Limited, Unit 402, 4/F., Grand Trend Building, 31 Heung Yip Road, Wong Chuk Hang, Hong Kong. (NOTE: For telephone enquiries contact: 00 (+)(852)2522 7181 where original instructions were purchased.
You must bear the costs associated with making the warranty claim (such as the sending in of the product for repair or replacement).
We will assess the defect and (as long as none of the exclusions above apply, will repair, replace, or refund you as the case may be. We may also repair or replace with goods or parts of a similar nature the repaired or replaced product (or you by the channel through which it was submitted to us.