# anko

## Tie Dye Kit



#### SET UP:

- 1. cover your work area with plastic covering, such as a plastic tablecloth or garbage bags.
- 2. prewash and dry the fabric before dying it, this will remove anything in the fabric that prevents the dye from being absorbed.
- 3. have all tools you need at the work area.

### START:

- 1. wear old clothes or an apron.
- add water to each bottle of dye powder, replace the cap tightly, shake the bottles until the dye is completely dissolved.
- 3. lay the fabric out flat on the working table, fold, twist or scrunch the fabric
- 4. use the rubber bands to hold the fabric firmly in place
- 5. wear gloves and squirt the dye onto the fabric.
- 6. put your dyed fabric into a plastic zip-top bag(not included), simply leave the closed bag in a safe place, the dye will need to set for 24 hours.
- 7. remove the rubber bands and check out your design, put the dyed fabric flat on a couple of thickness of paper towels to dru.
- 8. wash the dyed fabric several times in a washing machine with no other clothes, then hang to dry.

#### NOTE:

For brighter colours, add less water in to the due powder, for lighter shades, add more water.

read through the instruction and warning on this sheet before beginning. keep this instruction sheet for future reference.

WARNING: ADULT SUPERVISION AND ASSISTANCE REQUIRED.

MARNING: CHOKING HAZARD SMALL PARTS. NOT FOR CHILDREN UNDER 3 YEARS.

CAUTION: DYES ARE PERMANENT AND WILL STAIN. PROTECT YOUR HANDS, CLOTHES AND WORK AREA. WEAR GLOVES!

18cm