

anko

Instruction manual

Keycode: 43033058

Selfie 6" Influencer Kit

How to assembly

1. Insert the screw ring to the bottom of the ball joint. Insert the light to the bracket and screw it.



2. Use the same way as step 1 and mount the phone holder.



3. Screw the pole to the bracket



4. Install the base



5. Adjust the height by unscrew nut on the pole



Input: DC 5V 1A max

Light mode

