## **Assembly Instructions** 43142439 3 TIER SHOE CABINET

TOOLS REQUIRED: PHILLIPS HEAD SCREWDRIVER, HAMMER (NOT PROVIDED).

## **WARNING:**

THIS PACKAGE CONTAINS SMALL PARTS AND SHARP POINTS. KEEP AWAY FROM CHILDREN AND BABIES.

THIS PRODUCT MUST BE ATTACHED TO THE WALL TO PREVENT TIPPING OVER.

IT IS RECOMMENDED FOR 2 PEOPLE TO ASSEMBLE/MOVE THIS ITEM TO AVOID ANY POTENTIAL INJURY AND/OR DAMAGE.

MAXIMUM SAFE LOAD: 10KG FOR TOP PANEL, 5KG FOR INSIDE DRAWER.

## **Hardware list**

	а	6x35mm	10pcs
<b>®</b>	b	15x9.5mm	10pcs
	С	6x30mm	10pcs
	d		6pcs
0	е		6pcs
	f		3pcs
	g		3pcs

	h	M4x12mm	18pcs
٧	i		6pcs
8	j		18pcs
	k	M4x25mm	18pcs
	I	20x150mm Ø3.5x12mm	2pcs
6	m	Ø6x30mm Ø4x35mm	2pcs
<b>Summ</b>	n	M4x13mm	6pcs





