

## Candle Making Silicone Mould Instruction Manual

- › 1 flower mould
- › 11cm(H) x 5cm(Dia.)
- › 1 mould uses 200g of ANKO soy wax

### What you will need:

- › ANKO Candle Making Soy Wax
- › ANKO Wick Rope
- › ANKO Wick Holders
- › Disposable Mixing Stick
- › Disposable Measuring Cup
- › Disposable Gloves
- › Disposable Plastic Sheet or Cover



### Instructions:

1. Wear a pair of disposable gloves and lay down a disposable plastic sheet over your work area.
2. Cut a 20cm piece of ANKO wick rope and thread one end of the wick rope through the small hole in the silicone candle mould. Place the silicone mould on your work station with the big opening facing up.
3. Using a wick holder, thread the wick rope through the hole and place over the top of the silicone mould. This will keep the wick rope in place.
4. To melt the soy wax, follow the instructions on ANKO candle making soy wax packet. Note: The flower pillar mould holds 200g ANKO soy wax.
5. Once wax is melted, add in ANKO candle making wax dyes and stir through until melted (optional).
6. Pour the soy wax mixture into the silicone mould and allow to harden for up to 24 hours.

KEYCODE: 43-245-345

MADE IN CHINA

FOR AU/NZ: IMPORTED FOR KMART  
STORES IN AUSTRALIA AND NEW ZEALAND.

KMART CUSTOMER SERVICE  
AU: 1800 124 125 NZ: 0800 945 995