

INSTRUCTION MANUAL

PART LIST:

- 01: INFLATABLE BOUNCY CASTLE x 1PC
- 02: ANCHOR X 8PCS
- 03: REPAIR PATCH X 2PCS

WARNING!

1. Before using the product, carefully check if there are any leaks or broken parts.
2. Avoid damaging the product by clearing your setup area of sharp objects.
3. Do not use the product if it is leaking or damaged.
4. Do not over-inflate.
5. Do not use as a jumping device in water.
6. Do not exceed the maximum weight while in use: **85kg**.
7. Adult assembly required.
8. Place the product on a level surface at least 2 meters from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires.
9. The product shall not be installed over concrete, asphalt or any other hard surface.
10. User should not face the sun while using the product.
11. For family domestic use only.
12. For outdoor use only.
13. Keep assembly and installation instructions for future reference.
14. Children should be supervised at all times.
15. For children aged 3-6 years. Cannot be used by more than 3 children at the same time.
16. Anchors are to be installed to prevent overturning or lifting when in use. Take into account the soil conditions when installing to ensure stability.
17. Anchors shall be placed level with or under the ground in order to reduce tripping hazards.
18. Bouncy castle should be installed over impact absorbing surfaces such as sand, wood-bark chips, rubber and foam.
19. Appropriate clothing should be worn when using the bouncy castle to avoid friction burns.
20. Product is not safe if the anchorage system provided is not used, do not use the product in rain, wind, or in adverse weather conditions.
21. Do not exceed the maximum height of the top surface of the platform while in use: 30cm.
22. Consumer information sheet for playground surfacing material or specific surfacing guidelines for the product that are consistent with Annex B

Table B.1--Fall height in millimeters from which a life-threatening head injury would not be expected

Type of material	Depth of surfacing material		
	150mm	150mm	150mm
Double shredded bark mulch	1800mm	1800mm	1800mm
Wood chips	1800mm	1800mm	1800mm
Fine sand	1500mm	1500mm	1500mm
Fine graded	1800mm	1800mm	1800mm

INFLATION AND ASSEMBLY

1. Spread out the product.
2. Open the safety valves. Inflate according to the following steps: a) The base of castle; b) The four pillars; c) The four fences. d) Fix the strap on the lawn by using the anchor (See figure 1). Be sure to close the safety valves after inflation.




figure 1

DEFLATION

Open and pinch the safety valves to deflate.

REPAIR

If a chamber is damaged, use the provided repair patch.

1. Completely deflate the product.
2. Clean and dry the damaged area.
3. Apply the repair patch and smooth out any air bubbles.

CLEANING AND STORING

1. After deflation, use a damp cloth to gently clean all surfaces.

Note: Never use solvents or other chemicals that may damage the product.

2. Store in a cool, dry place and out of children's reach.
3. Check the product for damage at the beginning of each season and at regular intervals when in use.

Made in China