

# 42962847 WHITE PICTURE RAIL 55CM

Please read instructions carefully. Be sure you have all parts before you begin to assemble. Assemble furniture on a clean, flat surface such as carpet to avoid scratching.

## Attention:

- To ensure easy assembly we advise all fittings be finger tightened during the initial assembly.
- Once the product is assembled all fittings should be fully tightened.
- We recommend a periodic check on all fixing points to make sure they remain fully tightened.
- Do not tighten the screws before all screws are in place.

This package contains small parts and sharp points, keep away from children and babies until assembly is complete.

**Max safe load limit:** 5 kg

## Maintenance:

Wipe clean with a soft damp or dry cloth. Never clean with chemical cleaners.

