
MAGNETIC DRAWING BOARD

INSTRUCTIONS



Batteru Instruction



Mode 1: Learn and write the Uppercase Letters, Numbers

Press a letter or number button, it will identifies and reads out that letter or number, and the LCD screen shows how to write the letter (uppercase) or the number.

Mode 2: Learn and write the Lowercase Letters, Numbers

Press a letter or number button, it will identifies and reads out that letter or number, and the LCD screen shows how to write the letter (lowercase) or the number.

Mode 3: Learn drawing

Press a letter button, it will reads out an object beginning with that letter, and the LCD screen displays a picture of that object, then shows how to draw it.

Press a number button, it will reads out that number, the LCD screen displays a picture of that number, then shows how to write it.

Mode 4: Learn spelling

Press a letter or number button, it will spells a word beginning with that letter or number, then the LCD screen shows the spelling and / or animation of that word or number.

Mode 5: Ouiz Time

It asks the plauer to find the missing letter / spell a word / find the uppercase letters / find the lowercase letters in random. Press the correct button to answer.

Mode 6: Music Tunes

Press any letter button to hear that letter sung in the 'Alphabet Song' tune. Press the 'pause/song' button to play the entire alphabet song.

WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (+ AND -). ADULT SUPERVISION REQUIRED. DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES, NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION, RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED, REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED, BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY, DO NOT DISPOSE OF IN FIRE,

PRODUCT MAY VARY FROM THE IMAGE SHOWN PLEASE KEEP THE PACKAGING FOR FUTURE REFERENCE. SURFACE CLEAN ONLY, WIPE WITH A DAMP CLOTH.

⚠ WARNING: CHOKING HAZARD-SMALL PARTS. NOT SUITABLE FOR CHILDREN UNDER 3 YRS.

WARNING: FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.

MADE IN CHINA KEYCODE: 43027927

WARNING: THIS PRODUCT CONTAINS SMALL MAGNETS. SWALLOWED MAGNETS CAN STICK TOGETHER ACROSS INTESTINES CAUSING SERIOUS INFECTIONS AND DEATH, SEEK MEDICAL HELP IF MAGNETS ARE SWALLOWED OR INHALED.