

THIS MUST BE ASSEMBLED BY AN ADULT BEFORE USE.

THIS PRODUCT CONTAINS SMALL PARTS AND IS NOT SUITABLE FOR CHILDREN UNDER 36 MONTHS SMALL PARTS CHOKING HAZARD

CHILDREN MUST NOT USE THE EQUIPMENT UNTIL PROPERLY INSTALLED.

ONLY FOR DOMESTIC USE.

FOR OUTDOOR USE.

ADULT SUPERVISION IS REQUIRED.

RETAIN PACKAGING FOR FUTURE REFERENCE.

THIS PRODUCT IS INTENDED FOR USE BY CHILDREN AGED 6+ YEARS

CHECK ALL FASTENINGS REGULARLY AND OFTEN. FAILURE TO DO THIS MAY RESULT IN THE PRODUCT MALFUNCTIONING, AND CAUSING INJURY.

THIS IS USED TO BLOCK SUN, REMOVE THE SUN SHADE IN RAIN OR SNOW OR STRONG WIND CONDITIONS.

Trampoline Sun Shade

Key code: 43032860

INSTRUCTIONS FOR ASSEMBLY AND USE.

PLEASE RETAIN FOR FUTURE REFERENCE.

