








# Assembly Instructions



**⚠ CAUTION:**  
 ADULT ASSEMBLY IS REQUIRED. HARDWARE CONTAINS SCREWS WITH SHARP POINTS. KEEP UNASSEMBLED PARTS OUT OF THE REACH OF SMALL CHILDREN. ADULT SUPERVISION IS RECOMMENDED.

**WARNING!**  
 CHILDREN MUST NOT USE THIS PRODUCT UNTIL PROPERLY INSTALLED. ADULT SUPERVISION IS REQUIRED. ONLY FOR DOMESTIC USE. FOR INDOOR USE ONLY. THIS PRODUCT IS INTENDED FOR USE BY CHILDREN AGED OVER 3 YEARS.

**⚠ WARNING**  
 CHOKING HAZARD-SMALL PARTS. NOT SUITABLE FOR CHILDREN UNDER 3 YEARS.



**CAUTION:**

ADULT ASSEMBLY IS REQUIRED. HARDWARE CONTAINS SCREWS WITH SHARP POINTS. KEEP UNASSEMBLED PARTS OUT OF THE REACH OF SMALL CHILDREN. ADULT SUPERVISION IS RECOMMENDED.

**WARNING!**

CHILDREN MUST NOT USE THIS PRODUCT UNTIL PROPERLY INSTALLED. ADULT SUPERVISION IS REQUIRED. ONLY FOR DOMESTIC USE. FOR INDOOR USE ONLY. THIS PRODUCT IS INTENDED FOR USE BY CHILDREN AGED OVER 3 YEARS.



**WARNING**

CHOKING HAZARD-SMALL PARTS. NOT SUITABLE FOR CHILDREN UNDER 3 YEARS.