


PAPER:

80gsm
Bright white uncoated paper

PRINT COLOURS:



PRINT FINISH:

Double sided
Folded in the centre



CHANGE LOG CREST INTERNAL USE ONLY

ARTWORK SHOULD NOT BE AMENDED WITHOUT PRIOR AGREEMENT FROM CREST.
ALL ARTWORK MUST BE APPROVED BY CREST PRIOR TO MASS PRODUCTION.
IF THERE ARE QUERIES ABOUT THIS ARTWORK PLEASE CONTACT:
EMAIL: design@crest.com.au

THANK-YOU.

anko

Bluetooth® On-Ear Headset with Rotatable Microphone Operating instructions



12 month warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on **1800 124 125 (Australia)** or **0800 945 995 (New Zealand)** or alternatively, via Customer Help at **kmart.com.au** for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

includes:


- › Bluetooth® headphones
- › charging cable
- › braided headphone audio cable



WARNING Do not dispose of unit in fire or water. › Never attempt to disassemble and reassemble. › Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. › Check with your local authority for recycle advice. › Keep your device and all accessories out of the reach of children and animals. › Small parts may cause choking or serious injury if swallowed. › Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C). › Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device. › Do not allow your device to get wet—liquids can cause serious damage. › Do not handle your device with wet hands.

43-161-423

Function overview:



How to use these headphones:

Function Operation

Pause Press ►|| button

Play Press ►|| button

Next Song Press and hold ►►/+ button

Previous Song Press and hold ◄◄/- button

Volume Up Press ►►/+ button when the volume is adjusted to maximum you will hear a beeping sound.

Volume Down Press ◄◄/- button

Answer Call Press ►|| button

End Call Press ►|| button

Decline Incoming Call Press and hold ►|| for about 2 seconds

Redial Press ►|| twice in quick succession

Voice assistant Press and hold ►|| for about 2 seconds

Power ON / OFF

Power ON
Move the power switch to the "ON" position. LED indicator will flash red and blue

Power OFF
Move the power switch to the "OFF" position

Pairing the headphone with Bluetooth devices

› Once the headphone is powered on, it will enter into pairing mode with voice prompt of "power on" and the LED indicator will flash red and blue. The headphone will pair to the latest paired device automatically if available.

› if not previously paired, search the bluetooth list on your electronic device for the pairing name **KM43161423**, then click to pair with your headphone.

› Disconnecting the headphone from or turning "off" Bluetooth on, your electronic device will return the headphone into pairing mode with the LED indicator flashing red and blue. The headphone can now be paired to a different device.

Phone calls

› Press phone button to pick up/hang up phone calls. press and hold t reject incoming call.

› Press the phone button twice in quick succession to redial.

Playing music

When the headphone connects with the electronic device via Bluetooth® you can enjoy music through the headphone wirelessly.

You can also connect the braided audio cable and listen to music when the headphone's battery is flat.

Battery Charging

This Bluetooth headphone is powered by rechargeable Li-polymer battery.

Please use the provided USB cable to recharge the battery.

› Connect charging cable with the headset USB port.

› Insert USB charging cable into a suitable USB port.

› LED Indicator turns RED to show battery is charging.

› LED Indicator turns OFF when battery is fully charged.

› It takes about 2.5 hours to fully charge the battery.

Specifications:

Model No:
43161423

Version:
V5.1 multimedia hi-fi Bluetooth chipset

Support profiles:
A2DP/AVCTP/AVDTP/AVRCP/HFP/SPP/SMP/ATT/GAP/GATT/RFCOMM/SDP/L2CAP

Working Distance:
10 Meters

Music Time:
> up to 21 hours

Talk time:
> up to 20 hours

Standby time:
> 100 Hours

Charging voltage:
5V d.c.

Battery capacity:
450mAh

Charge time:
2.5 Hours

Cable length:
1.1m

Pairing window time:
5 Minutes

Non-play automatic power save mode:
After 30 seconds the headphone will enter power save mode and it can be activated by short pressing the ►|| button.