

正面

100mm

anko
Instruction Manual
Vlogging Kit
43277261



Safety Instructions:

Please read the instruction manual before using this device and follow all the safety instructions to avoid damage caused by improper use.

1. Keep the instruction manual for future reference. Should this device be given to a third party, then this instruction manual must also be handed over.
2. Keep the device away from all hot surfaces and naked flames.
3. Do not immerse the device in water or in other liquids.
4. Do not use the device in wet conditions.
5. Do not use the tripod in windy conditions or on an uneven surface.
6. Do not use the device if it is damaged.
7. This device is not a toy. Children should be supervised to ensure they do not play with the device.

Packaging include:

- LED light X1
- Microphone X1
- Foldable Tripod Stand X1
- Telescopic rod X1
- Phone clip X1
- 3.5mm Aux cable for smartphone X1


182mm

背面



Use

1. Open the tripod, rotate and unscrew the telescopic rod at the bottom, and then screw the end of the telescopic rod with the screw hole on the screw of the tripod and tighten it.
2. Attach the phone holder to the telescopic rod then tighten the screw.
3. Attach the LED light to the phone clip then tighten the cold shoe mounts.
4. Attach the microphone to the LED then tighten the cold shoe mounts.
5. Unfold the tripod legs and place it on a flat surface, adjust the telescopic rod's height you need.
6. Put in 2 X AA batteries (not included) into the LED light back side. Long press the power button to turn on / off the light. Short press the brightness button to adjust the brightness.
7. Adjust the width / length and place your smart phone in the phone holder.
8. Plug one side of 3.5mm AUX cable into the microphone, then plug another side into your phone.



Note: Smartphones without a 3.5mm jack will require an adapter such as Lightning to 3.5mm for iPhones or USB-C to 3.5mm for certain Android devices (Adapters not included).

Specification

1. LED Light Power: 1.5W
2. LED Light working voltage: DC 3V
3. LED Light Battery: 2 X AA batteries (Not included)

12 Month Warranty

Thank you for your purchase from Kmart.
 Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.
 Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect. Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at Kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.
 Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
 For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.