


Acticity Easel

Key Code : 43311859

Read and follow instruction carefully and keep for future reference.



WARNING:
CHOKING HAZARD - SMALL PARTS.
NOT FOR CHILDREN UNDER 3 YEARS.

MADE IN CHINA
FOR AU / NZ: IMPORTED FOR KMART
STORES IN AUSTRALIA AND NEW ZEALAND.

⚠ WARNING:

- ADULT ASSEMBLY AND SUPERVISION REQUIRED.
- UNASSEMBLED PARTS CONTAIN SCREWS AND WITH FUNCTIONAL SHARP POINTS. PLEASE KEEP UNASSEMBLED PARTS AWAY FROM CHILDREN.
- CHECK CONDITION OF ITEM REGULARLY, AS SCREWS MAY LOOSEN WITH USE OVER TIME. TIGHTEN SCREW FITTINGS IF NECESSARY.
- REMOVE ALL THE TAGS, LABELS AND PLASTIC FASTNRTS BEFORE GIVING THIS TOY TO YOUR CHILD.
- STOP USING THIS PRODUCT IF THERE IS ANY LOOSE OR MISSING FASTENERS, JOINTS OR BROKEN PARTS.
- ANY ADDITIONAL OR REPLACEMENT PARTS SHOULD ONLY BE OBTAINED FROM THE MANUFACTURER OR DISTRIBUTER. NEVER SUBSTITUTE PARTS.
- COLOUR AND CONTENT MAY VARY FROM IMAGE SHOWN.
- WASH HANDS THOROUGHLY AFTER USE.

PARTS LIST

A x1	B x1	C x1	D x1
E x1	F x2	G x1	H x1
I x1	J x1	K M4X35mm x2	L x1
M x1	N x2	O x1	Q M5X36mm x8
S Chalk x12	T Marker x1	P x6	R x6
U Duster x1	V Magnetic Letters & Numbers x41		

