Assembly Instructions 43323067 ARCH HOOK & SHELF

Care Instructions:

Wipe clean with a dry cloth. Do not use abrasive material and solvents. Check and tighten all parts regularly. Keep away from water and direct sunlight. Do not place hot items such as coffee cups directly on the surface. Store in a dry place. For indoor and domestic use only.

Warning:

Do not use until all screws are firmly secured. Adult assembly required. Failure to follow these warnings could result in serious injury.

Maximum loading weight: 3kg for shelf, 1kg per hook.





