

Wooden Shopping Cart


Assembly Instruction

43347223






Product image




PARTS LIST



HARDWARE

- A   x4
- B  x18
- C  x2
- D  x2

Tools Required (Not Included)



Cross screwdriver

ASSEMBLY

CAUTION: ADULT ASSEMBLY AND SUPERVISION REQUIRED.

WARNING: UNASSEMBLED PARTS CONTAIN SCREWS AND WITH FUNCTIONAL SHARP POINTS, PLEASE KEEP UNASSEMBLED PARTS AWAY FROM SMALL CHILDREN

CAUTION: PLEASE CHECK CONDITION OF ITEM REGULARLY, AS SCREWS MAY LOOSEN WITH USE OVER TIME. TIGHTEN SCREW FITTINGS IF NECESSARY. STOP USING THIS PRODUCT IF THERE IS ANY LOOSE OR MISSING FASTENERS, JOINTS OR BROKEN PARTS.

CAUTION: THIS IS A TOY, INTENDED FOR ROLE PLAY ONLY.


WARNING: DO NOT SIT AND STAND INSIDE OR ON TOP OF IT.

WARNING: FOR SAFETY REASONS, REMOVE ALL TAG, LABELS AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.


MADE IN CHINA

Read and follow instruction carefully and keep for future reference.

Step 1




Step 2




ASSEMBLY


Step 3




Step 4




Step 5




Step 6




Step 7




Step 8



Step 9



Step 10



Step 11

