



K: 43351756 | T: 68768683 (Model: JLR-78394)

Bluetooth Oval Headphones

Instruction manual



Please read all the information carefully before you use the product and keep the manual for future reference.

Packing list:

Headphone*1


1.2m Type-C to 3.5mm Audio Cable*1

Type-C Charging Cable*1

User's Manual*1

Production structure

1. Power button
2. Multi-function button
3. Volume + button
4. Volume - button
5. Indicator light
6. Charging port
7. Microphone



Bluetooth headphone turn ON/OFF

1. Turn on: Long press the power button for 2 seconds, the blue light of the pairing indicator will be on for a few seconds.
2. Turn off: Long press the power button for 2.5 seconds.

Bluetooth connection

Follow the steps (Please make sure that your phone is built-in Bluetooth function)

1. Turn on the headphone, the pairing indicator flashes alternately with blue and red, the headphone enter the pairing status.

(Note: The headphone can automatically enter pairing status after power on if there is no re-connection. As the headphone can automatically reconnect with the last device that you had paired. To re-connect, you just need to turn it on.)

2. Activate the Bluetooth function and search for “anko43351756” referring to your phone instructions.
3. Manually click “anko43351756” to connect.

Answering incoming calls

Press the multi-function button to answer the call.

Tip: Since some mobile phones default to answer calls via their own receiver, please refer to the instructions of your phone and set on your phone.

End the current call

Press the multi-function button to end the current call.

Reject incoming calls

Long press the multi-function button to reject incoming calls.

Voice assistant

Long press the multi-function button for 1.5 seconds to activate the voice assistant.

Music playing

1. Play/Pause: Press the multi-function button to play music.
2. Select the previous song: Three press the multi-function button to switch the previous song.
3. Select the next song: Double press the multi-function button to switch the next song.
4. VOL+: Press volume + button to increase the volume.
Long press the volume + button to gradually increase the volume.
5. VOL-: Press volume - button to decrease the volume.
Long press the volume + button to gradually decrease the volume.

EQ mode

4 EQ modes: Default EQ/Clear voice/low voice mode/Deep bass. Three times press the power button to switch the EQ modes.

Wired mode: Audio Cable connecting To Audio Jack

1. Plug and play: Connecting the headphone to a music player with the provided audio cable, the headphone can be used as wired headphone without starting.
2. In this mode, you can't use any function of the headphone, including volume adjustment, power button and so on.

Note: The Bluetooth headphone will automatically switch off and become a wired headphone after plugging in the USB-C to 3.5mm audio cable.

To charge the headphone

1. As product is built-in non-removable and rechargeable battery, please use the provided charging cable to charge.
2. Fully charge the product before the first use. It takes 3 hours to charge for the subsequent use.
3. The red light of the charging indicator is always on when charging, when the battery is fully charged, the charging indicator goes out.

Notes

- a. Please choose the charger that is certified by the regular manufacturer.
- b. The battery performance may decrease as repeating charging and using the product. It's a normal phenomenon for all rechargeable batteries.

Specification:

Version: V5.3

Speaker: Φ 40mm

Impedance: 32 Ω

Sensitivity: 103dB \pm 3dB

Frequency response: 20Hz-20KHz

Bluetooth operating distance: APPROX 10M

Battery: 400mAh

Play time: APPROX 20 HOURS (80% volume)

Talk time: APPROX 18 HOURS

Charging time: APPROX 3 HOURS

Charging port: Type-C port

Product size: 185*197*76mm

Net weight: 206g

Input voltage: 5V/1A

Warnings

1. Please follow the instruction to operate.
2. Please charge the headphone with input power below 5V/1A, in order to protect the battery;
3. Please store or use the headphone in a normal temperature environment.
4. Please keep the headphone from heat source, such as radiators, hot air regulators, stoves, or other heat generating instruments. As it is not anti-high temperature.
5. Don't jam the ports of the headphone, such as charger port, LED port and microphone etc.
6. In order to protect your hearing and extend the headphone service life, it is not recommended to adjust the volume to the maximum level for a long time.