


Junior Tricycle Ride On Instruction Manual




Parts List




Assembly Instruction

Step 1: Place main seat (H) into middle of fork(I), align and slide axle(E) through from bottom.


Step 2: Turn buggy upside down, place on a solid surface, capped side up. Place cap nut(A) in the cap nut tool(C) and hold at opposite end of the axle(F) in the gap under the handlebar. Using hammer, tap the top of axle until cap nut is securely fixed onto the axle. Step 3: Place 1pc plastic spacer(D) on the two side of wheel(J), please note the direction of plastic spacer(D) on the wheel, ensure the two narrow ends are outward.







Step 5: Place each of 2pcs plastic spacers(D) on the two side of wheel(J), please note the direction of plastic spacer(D) on the wheel, one narrow end is inward, the other narrow end is outward.

Step 6: Connect part of step 4 and the two part of step 5 with axle(G) and 2pcs plastic spacers(D), then assemble the cap nut(B) at the end of axle by using hammer and cap nut tool to fix the two parts.





NOTE: Tap lightly with hammer to secure cap nut in place. Hammer not included.



Warning

The maximum user weight is 20kg. Only one rider at any time. Adult assembly required. Ensure there is constant adult supervision at all times while in use. Always wear a helmet and protective equipment. Do not ride at night or in wet weather. Never use on public roads, hills, sloped driveways, near motor vehicles or swimming pools. Read and follow instruction manual. Always wear shoes.

Choking hazard small parts, not suitable for childen under 3 years prior to assembly.

K: 43-379-910 | T: 69-555-190

MADE IN CHINA
CUSTOMER SERVICE:
KMART All: 1800 124 1

KMART AU: 1800 124 125 KMART NZ: 0800 945 995 TARGET AU: 1300 753 567