




anko

Manual



USB: Type C


Battery Charging : Indicator light—RED

Battery finish charge : Indicator light—Green



Step 1:

**Push button switch to put lamp on standby,
the switch will turn white.**



Step 2

Press this to turn on or off.