

3+
YEARS

77 HOLE BUBBLE BLASTER



BATTERY INSTALLATION:

1. Loosen the screw to open the battery cover.
2. As shown in diagram 1, remove the battery cover, connect the rechargeable battery with connector and close the battery cover.





Diagram 1

HOW TO CHARGE:



1. Loosen the screw to open the battery cover.
2. Separate the rechargeable battery from connector.
3. Connect the USB charging cable with rechargeable battery first (The battery connector will only fit in one way, do not force the connectors together), then plug the large end of USB cable into a 5Vd.c. 2A charger (not supplied) or USB port only. The red LED light on the USB charging cable will light up and the green LED light will flash when charging.
4. The green LED light will light up and will be solid after it has finished charging. Disconnect the USB charging cable from the USB port and then disconnect the rechargeable battery with USB charging cable.

Attention: Do not charge battery immediately after each play. Let the battery cool down for a while.

Rechargeable lithium battery pack +USB charging cable (Included).

HOW TO USE:



1. Pour bubble solution into the plate. Ensure enough bubble solution is added.
2. Fully immerse the tip of the bubble blaster in bubble solution for a while.
3. Pull the trigger to produce bubbles.

WARNING: THIS TOY PRODUCES FLASHES THAT MAY TRIGGER EPILEPSY IN SENSITISED INDIVIDUALS.

WARNING: THE TOY IS ONLY TO BE CONNECTED TO CLASS II EQUIPMENT BEARING THE SYMBOL.

WARNING: DON'T DRINK THE BUBBLE SOLUTION. NOT INTENDED FOR HUMAN CONSUMPTION. AVOID SWALLOWING THE BUBBLE SOLUTION. ADULT SUPERVISION REQUIRED. IF EYES GET IN CONTACT WITH BUBBLE SOLUTION, IMMEDIATELY FLUSH WITH PLENTY OF WATER. IF ANY IRRITATION OCCURS, SEEK MEDICAL ATTENTION IMMEDIATELY. IMPROPER USE CAN CAUSE STAINS ON CLOTHING. RECOMMENDED FOR OUTDOOR USE ONLY. DO NOT BLOW IN FACE, EYES OR HAIR. WASH HANDS THOROUGHLY AFTER USE.

CAUTION: CONTAINS FRAGRANCES THAT MAY CAUSE ALLERGIES. PACKAGING IS NOT A TOY. REMOVE ALL PACKAGING BEFORE GIVING THE TOY TO CHILDREN. KEEP THIS INFORMATION FOR ANY POSSIBLE CORRESPONDENCE IN FUTURE.

CAUTION: PROLONGED CONTACT CAN CAUSE SLIGHT IRRITATION. WASH HANDS AND AFFECTED SKIN THOROUGHLY WITH SOAP AND WATER AFTER USE.

K: 43-386-437 | T: 69-563-164

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567