


210mmX95mm

Instruction Manual

Camp Light With String

Keycode: 43399253

Product analysis



TENT



KNAPSACK



CAMP



PARTY

Made in China

Gear operation instructions




Press the button to switch the cycle gear:
string lights warm light-string lights RGB
alternate flashing-string lights RGB
breathing - SMD warm white-string lights
warm light - SMD strong light - off.


First long press more than 3 seconds XTE
strong light - second short press weak light
- third short press flash.

After 8 seconds of lighting in any mode,
press the switch to turn off.


Light string



step 1



step 2



step 3

Open the side light string cover in
the direction of step 1.

Open the side light string cover, pull
out the light string to use (follow the
direction of the arrow in step 2).

Rotate the storage handle after use
to retract the light string (follow the
direction of the arrow in step 3).

Charging instructions

Built-in rechargeable battery, which can be
charged by connecting the USB cable to the
TYPE-C interface.



Indicator status	Power state
●●●●	Four light 75%-100%
●●●○	Three light 50%-75%
●●○○	Two light 25%-50%
●○○○	One light ≤25%

Product parameter

Lamp beads: 9.8 meters yellow light + RGB string lights + 36 SMD + XTE LED	
Brightness: 80-250LM	Charging: TYPE-C 5V 1A
Endurance: 3-6h	Output: USB output
Waterproof grade: IPX4	Charging time: about 3 hours
Material: PC+ABS+magnet	Product size: 100 x 30mm
Battery capacity: Polymer 1200mah	Weight: 200g

Precautions

Instructions for use:

- Please refer to the operating instructions for switching the lighting mode.
- Do not use this product in extremely cold and extremely hot environments below minus 10°C or above minus 60°C.
- This product is only for ordinary waterproof IPX4. Do not use it in diving, otherwise it may cause the circuit failure of the lamp due to water seepage.

Energy:

- This product is only suitable for the original built-in lithium battery, please do not disassemble and replace it by yourself.
- Please use a high-quality power socket and the standard USB charging cable to charge this product.
- Do not charge in the lighting mode.

Warning:

- Before turning on the light, please read this manual carefully for proper use and maintenance.
- Children should use this product under the supervision and guidance of adults.
- Do not disassemble this product by yourself.
- Do not modify this product by yourself.
- Do not pull hard if the light string is jammed; check its direction to avoid damage.