


AXE THROWING GAME

Key Code: 43403370

Warning

- **CHOKING HAZARD**, small parts. Not suitable for children under 3 years.
- Adult assembly required.
- Don't aim at face and eyes while playing game.

Parts List



Target
A x 1pc



Throwing axe
B x 3pcs



Throwing star
C x 3pcs



2-way connector
D x 4pcs



Long tube
F x 4pcs



Short tube
G x 3pcs



3-way connector
H x 2pcs

Assembly Instructions

Step 1. Connect 1pc short tube (G) and 2pcs 2-way connector (D) as well as 2pcs long tube (F) together to form a "U" shape part. Repeat for the other one (Fig.1).

Step 2. Connect 1pc short tube and 2pcs 3-way connector (H) together (Fig.2).




Fig.1




Fig.2

Step 3. Connect the three parts of step 1 & 2 together to form a "L" shape frame (Fig.3).

Step 4. Put the target (A) on the frame, ensure the brackets at the back of target is attached on the frame firmly (Fig.4). Then you can enjoy your game now.




Fig.3



Fig.4

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567