


anko

Pet Water Fountain Mat




Contents:



Instructions:

Step 1 Connect the hose to the fountain by inserting the hose into the connector. Ensure that the hose is connected properly to stop the hose from popping out.



Step 2 Turn on the hose to make the water come out.



WARNING: PET TOY - NOT INTENDED FOR CHILDREN.

IT IS THE RESPONSIBILITY OF THE PET OWNER IF THIS TOY IS SUITABLE FOR THEIR PET'S STYLE OF PLAY. NO PET TOY IS INDESTRUCTIBLE AND CAN BE DAMAGED DURING PLAY. FOR YOUR PET'S SAFETY, INSPECT REGULARLY AND REMOVE IF DAMAGED. ALWAYS SUPERVISE YOUR PET DURING PLAY.

CAUTION: ALWAYS SET UP THE WATER FOUNTAIN MAT ON A SMOOTH LEVEL SURFACE AND AVOID SHARP OBJECTS. ALWAYS ENSURE ADULT SUPERVISION FOR BOTH DOGS AND CHILDREN AROUND THE WATER FOUNTAIN MAT AT ALL TIMES.