

anko

Bluetooth® Portable Speaker with RGB



User Manual



K: 43-421-350 | T: 69-548-369
MODEL: EBS5-223439

Includes:

- › Bluetooth® RGB Speaker
- › USB A to USB C Charging Cable
- › User Manual

12 month warranty

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.


Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Statement

- This product shall not be connected to power supply source exceeding PSI (5V d.c. 1A).
- Battery cannot be subjected to high or low extreme temperatures, low air pressure at high altitude during use, storage or transportation.
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
- The apparatus is only suitable for mounting at height < 2m.
- The marking located on the bottom of the apparatus.

Contact for Kmart purchases	Contact for Target purchases
Kmart Australia Ltd. C/- Customer Service Centre 699 Springvale Road, Mulgrave Vic 3170 Customer Service: 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or via Customer Help at kmart.com.au	Target Australia Pty Ltd C/- Customer Service Centre 2 Kendall Street, Williams Landing, Vic. 3027 Customer Service: 1300 753 567 or via Customer Help at target.com.au/help/contact-us

Function overview:



- | | |
|--|------------------------------|
| 1. Hand Strap | 6. MIC |
| 2. RGB Light Display | 7. Volume Up/Next Song |
| 3. Power ON/OFF
Play/Pause
Answer/hang up call | 8. Volume Down/Previous Song |
| 4. Switch Bluetooth Mode/TF Mode/
AUX Mode | 9. TF Card Slot |
| 5. RGB Light Switch Button | 10. USB-C Charging Port |
| | 11. Charging Indicator |
| | 12. AUX-IN Port |

How to use this speaker:

Function Operation

Pause Press **⏸** button

Play Press **▶** button

Volume Up Press **+** key to increase the volume

Volume Down Press **-** to decrease the volume

Next Song Long press **⏸** key for 2 seconds to skip the track.

Previous Song Long press **▶** key for 2 seconds to skip the track

Power ON/OFF Long press **⏸** button 2 seconds

RGB Light Button Press **⊗** to switch RGB light modes

Specifications:

Model no:
EBS5-223439

Version:
Bluetooth V5.3

Working distance:
10 Meters

Output:
4.5W

Music time:
5-6 hours at 80% volume (RGB ON)
8-10 hours at 80% volume (RGB OFF)

Charging voltage:
DC= 5V

Battery capacity:
3.7V 1500mAh

Charge time:
2-3 Hours

IP Rating
IPX4

Power ON/OFF Button:

- › Press and hold ON/OFF button, the RGB lights up LED will flash.
- › Press to answer/hand up a call.
- › Short press to play/pause music.

Switch Mode

- › Click **⊗** to switch Bluetooth Mode/TF Mode/AUX Mode. No matter which mode (Bluetooth Mode/TF Mode/AUX Mode) you switch, you can hear the prompt tone to enter the mode then hear the music.

Bluetooth Mode

- › Once the speaker is powered on, will automatically enter to Bluetooth mode.
- › Search for "anko43421350" (bluetooth name) and connect from Bluetooth menu on the media device.
- › Once the speaker is successfully paired and connected, you will hear a prompt tone.
- › When the TF Mode/AUX Mode is disconnected, automatically reconnected Bluetooth mode.

RGB Mode

- › Short press to **⊗** changes the RGB light color (mode 1~model 5-off RGB lights), press the button for the sixth time to turn off the RGB lights.

AUX Function

- › Use a 3.5mm audio cable (not included) to connect your device through the AUX IN port. You will hear a prompt tone. Choose the music from your media device and play.

TF Card Play

- › Insert a TF card into the TF card slot, the speaker will play music automatically from the TF card. Supports playback of the following audio formats: WAV/MP3, maximum support 64GB.

TWS Pairing

- › To pair both speakers in TWS mode, long-press the volume up and volume down buttons on one speaker after powering them both on.
- › After successful pairing, you can search "anko43421350" from source device (eg. smart phone) and connect.

- › All actions performed on one speaker are automatically applied on another one speaker. Such as switching songs, volume up/down, Play/Pause and power-off; You also can control the volume up/down, switching songs, Play/Pause from source device (eg. smart phone).

- › Disconnect pairing:
Long press Volume Up and Volume Down at the same time on either of speakers to disconnect. The remaining BT connected speaker will keep working, and the disconnected speaker will go into standby mode.

- › Re-connection after disconnection:
Long press Volume Up and Volume Down on disconnected speaker to re-enter TWS pairing and re-connect the other speaker automatically (both speakers should be in Bluetooth mode).

Charging

- › This Speaker is powered by rechargeable Lithium battery. Please use provided USB C cable for charging (Plug the USB C end to the device charging port and the other USB A end plug into a PC USB port, wall charger or other 5V charging devices). The LED indicator displays red while charging and light off when fully charged.

Using the environment & storage environment

- › Operating environment
Temperature: -5 °C~45 °C
- › Storage environment
Temperature: -20 °C~60 °C

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc., and any use of such marks by KMART AUSTRALIA is under license.

