

anko

Instruction manual



K: 43430994 | T: 69733932

(Model: JLR-78083)

Desk Fan with Holder

To ensure correct operation and avoid damage, please read this user manual carefully before using this product.

Caution

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Please do not put your fingers into the gaps of the fan during operation to avoid injury.
- Do not use this product in damp environments or when hands are wet. If the product accidentally enters water or other liquids, immediately turn off the fan power switch and let it completely dry before trying again.
- Do not knock or hit the product, as repeated knocking or hitting may cause internal faults in the product.

- Avoid long-term storage of the product in high temperatures and environments. Please use at room temperature (0-40°C)

- If there are malfunctions such as abnormal burning smell or slow rotation speed of the bearing heater during use, do not continue to use it and cut off the power supply.

Battery caution

- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

- Battery cannot be subjected to high or low extreme temperatures, low air pressure at high altitude during use, storage or transportation.

- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.

- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.

- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

- The batteries contains materials hazardous to the environment, please discard them based on local requirement.

Specifications

Input: 5V / 800mA(Max)


Product size: 212*106*81mm

Rechargeable lithium battery

Charging time: approx 2~3 hours

Play time: approx 1~5 hours


Product details



Installation

1) Put the fan into the holder when you need to use the fan on the desk as the position below

and make sure the fan in correct positions.



2)The installation is completed and you can start to use the fan.

How to use

Press the power switch to start to use the fan.

1st press: power on, Low speed and working time approx 5 hours

2nd press: medium speed and working time approx 2 hours

3rd press: high speed and working time approx 1 hours

4th press: power off

How to charge

- The supplied USB charging cable should be inserted into the standard USB power source rated at 5V specification. The charging time is around 2~3 hours. The indicator will keep lighting in red during charging and turns green after fully charged.

- If the battery has totally run out, the fan will not work at all.

Note:

- Fully charge the appliance before first use.