

142.5mm

142.5mm

Step 3.

Place part B into the bottom of the assembled structure:

**Step 4.**

Connect part E to the assembled structure using the cardboard tabs as shown below:

Don't forget to fold the entrance paper as shown below:



WARNING: Pet toy – Not intended for children.
It is the responsibility of the pet owner if this toy is suitable for their pet's style of play.
No pet toy is indestructible and can be damaged during play.
For your pet's safety, inspect regularly and remove if damaged.
Always supervise your pet during play.

anko**Cat Christmas Scratcher Sleigh****Contents**

A.



B.



C.



D.



E.



A. Bottom & Side Paper x 1pc	B. Paper Scratcher x 1pc	C. Left Paper x 1pc	D. Right Paper x 1pc	E. Top & Side Paper x 1pc
------------------------------	--------------------------	---------------------	----------------------	---------------------------

Assemble instruction**Step 1.**

Open the bottoms and sides of part A, then connect them to the part D by using the cardboard tabs. Refer to the below images:



Don't forget to tuck the tabs in along the entrance holes as per below image:

**Step 2.**

Connect part C to the assembled structure using the cardboard tabs as shown below:



210mm

210mm