
anko

2.13M (7FT) CASHMERE CHRISTMAS TREE - TREE E KEYCODE K: 43441846 T: 70022148



Contents

- A. Tree Top
- **B.** Upper Body
- C. Lower Body
- D. Metal Stand



Instructions

- 1) Unfold the metal stands and make them perpendicular to each other. Carefully insert the bottom of tree section C into the tree stand. Make sure the pole is fully inserted into the stand and screws are tightened.
- 2) Insert Section B into Section C then secure into stand
- 3) Insert Section A into Section B
- 4) Lower all main branches on the bottom level and position so they are parallel to the floor, shape as desired.
- 5) For a better result, straighten and separate all the small branches. Then, bend slightly upward in a 'V' shape to match the rest of the tree.

Warnings:

- 1) This product is for indoor use only.
- 2) Keep product away from fire and other heat sources
- 3) Recommend saving instructions for future reference.

Packaging Up and Storage Tips

- 1) Remove all lights and ornaments.
- 2) Remove sections as places, Section A and Section B.
- 3) Slide legs down and remove from slots at the base of the tree truck.
- 4) Each tree section, the branches should be pressed against the stem before placing in carton.
- 5) Pack carton and store in a dry and damp free area.
- 6) Do not place product in direct sunlight or in an area where temperatures exceed 40 degrees.