## INSTRUCTIONS

## WARNINGS

(B) Warnings! BEFORE YOU USE YOUR LAMP. Check the lamp for damage before each use. If the lamp is damaged with cracks or scratches, switch off and unplug the lamp and discontinue use immediately. For indoor use only. The USB cable and power supply used with this item is to be regularly examined for damage to the cord, plug, and other parts, and in the event of such damage, they must not be used until the damage has been repeated. Keep out of each of young children. This product is not to be directly connected to the mains supply. Installation and operation of this lamp should be carried out by an adult. If the leguld in the lamp becomes exposed to floor/furnishing, remove and dispose as much of the leguld as possible, then use recommended deelaning methods for enough of water for whatever floor/furnishings are affected. If liquid content comes in contact with the skin, wash hands thoroughly with clean, fresh water. This item can be used with a compatible mains powered transformer. In its must be a short-circuit proof safety isolating transformer according to IEC 61558-2-16 or a toys transformer according to IEC 61558-2-7. Max Output SV DC 1A. LEDs are not replaceable.

Output SV DC 1A. LEDs are not replaceable.

This light is only to be connected to equipment bearing either of the following symbols:





## INSTRUCTIONS

© Use 3 x 15v type AAA batteries. Take care to fit batteries observing the plus & minus markings. Replace all used batteries at the same time. Do not mix used and new batteries, rechargeable, different types (alkaline or carbon zinc), or different brands of batteries. Only use batteries of the same type. Non-rechargeable batteries are not to be rechargeable batteries are to be removed from the product before being charged. Rechargeable batteries are not only to be charged under adult supervision. The supply terminals are not to be short-circuited. Exhausted batteries are to be removed immediately, To insert / replace batteries. Unscrew battery cover and insert batteries, observing polarity quide finsure battery cover is securely screwed in place before use. The cossed out wheeling symbol on this product is to remind you that waste electrical and electronic products, batteries and accumulators should not be disposed of with household waste. If you are unable to re-use or recycle your article it should be disposed of at a civic amenity site/local authority recycling facilities. Packaging (and instructions if included) must be kept since they contain important information.

WARRING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures

- Reorient or relocate the receiving antenna.
   Increase the separation between the equipment and receiv
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

## MADE IN CHINA

CUSTOMER SERVICE: KMART AU: 1800 124 125 KMART NZ: 0800 945 995 TARGET AU: 1300 753 567



K: 43-449-439 T: 69-961-274

