

anko

Mini Light Up Drawing Board

INSTRUCTION SHEET



1. Choose the picture card you want to copy.



2. Open the back and take out the markers. Insert the card into the mini light up drawing board.



3. Trace the card with the markers.



4. Press the heart button to turn on the light and see your picture glow! Cycle through different colours by pressing the button again.




5. Use the eraser cloth to rub out your picture and try again!



6. Copy one of the picture cards or create your own glowing pictures!

CHANGING THE BATTERY



Requires 3x AAA (1.5V) Batteries



Unscrew to remove battery cover

WARNING

Batteries are to be inserted with the correct polarity (+ and -).

Do not mix different types of batteries or new and used batteries.

Non-rechargeable batteries are not to be recharged.

Rechargeable batteries are only to be charged by adult.

The supply terminals are not to be short-circuited.

Remove battery from the toy when not in use for extended time or when batteries become exhausted. Battery installation by an adult is required.

Dispose of batteries responsibly. Do not dispose of in fire.

Not suitable for children under 3 years of age due to small parts which may cause a choking hazard. Please remove all packaging attachments before giving this product to a child.

Please retain all information for future reference. Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority for recycling advice.