

Dual Section Spin Mop Set Mopping System Installation Guide

Mop Assembly

- 1.Screw poles 1, 2 and 3 together tightly (see Fig. A).
- 2.Now that the mop handle pole is assembled, tightly screw the pole into the mop plate(see Fig.B)
- 3.Gently press the white back side of the microfiber mop pad onto the mop plate(see Fig.C).The smoother mop pad is more suitable for use on tile, the rough mop pad is more suitable for use on the wood floors.




Fig.A




Fig.B




Fig.C

How to use

- 1.Add clean water to the mop bucket (see Fig.D). Make sure the water level does not exceed the max fill line.You can pour water in from the two openings in the corners or open the plastic cover and add water to the base.
- 2.Gently unlock the grey latch on the lower part of the mop pole (see Fig.E).
- 3.Place the mop plate into the bucket.Begin plunging the mop handle up and down at least 10 times to complete the mop pad cleaning and drying process(see Fig.F).
- 4.Adjust the pole length to a comfortable height and close the grey latch on the lower part of the mop pole before mopping(see Fig.G).
- 5.When emptying the dirty water, pull-out the drainage plug, or lift the mop bucket handle and pour water(see Fig.G).




Fig.D



Fig.E




Fig.F




Fig.G




Fig.H

Dual Section Spin Mop Set Mopping System Installation Guide

Mop Bucket Assembly and Disassembly

1. Mop bucket will come fully assembled out of the box and ready for use. (see Fig.I).
2. To disassemble the mop bucket for cleaning, lift the inner bucket (see Fig.J).

Attention:

- (1) To assemble the bucket, press the outer bucket handle to the side with notch, then lift the inner bucket on the outer bucket (see Fig.J). Make sure the handles of inner and outer bucket on the same side (see Fig.K).
- (2) Make sure the arrows on the inner bucket cover and outer bucket aligned in a straight line before spinning (see Fig.L)



Fig.I




Fig.J




Fig.K




Fig.L

Cleaning Transparent Cover

After washing and drying mop, flush under the faucet to clean transparent cover (see Fig.M). Remove the dirt or hairs from comb (see Fig.O)




Fig.M

Cleaning And Disinfecting Products

Feel free to add cleaning or disinfecting products to the mop water for an even deeper clean. We recommend using streak and residue-free cleaners so that there is no need for rinsing.

Operating Tips

1. When washing mop, better hold your hand here (see Fig.N).
2. When washing mop, please remember "Spin slowly is wetting, spin fast is water removal".
3. "Spin slowly is wetting" means to pull the pole to the highest level and press the pole with power.
- After waiting 1-2 seconds, operate like just now. For the best result, please repeat the above operation 8 times.
4. "Spin fast is water removal" means to pull the pole to half level and press the pole with power and fast. For the best result, please repeat the above operation 6 times.




Fig.N



Before









After






Dual Section Spin Mop Set Mopping System Installation Guide

included	
Bucket*1	
Mop Plate*1	
Lower Pole*1	
Middle Pole*1	
Upper Pole*1	
Smooth mop pad*1 Rough mop pad*1	

anko



anko

Dual Section Spin Mop Set

