


CITY TRACK FIRE STATION







3+ YEARS



A		X8	H		X1
B		X8	I		X1
C		X261	J		X3
D		X4	K		X2
E		X1	L		X2
F		X1	M		X2
G		X1	N		X2

A. SLOPE X 8 PIECES
 B. SLOPE COLUMN X 8 PIECES
 C. TRACK X 261 PIECES
 D. WHITE RAILWAY X 4 PIECES
 E. FORK X 1 PIECE
 F. POLICE STATION WALL X1 PIECE
 G. POLICE STATION BASE X 1 PIECE

H. MOUNTAIN X 1 PIECE
 I. PALM TREE X 1 PIECE
 J. INDICATOR X 3 PIECES
 K. CAR X 2 PIECES
 L. WALL X 2 PIECES
 M. LOAD-BEARING COLUMN X 2 PIECES
 N. DOOR X 2 PIECES



WARNING: THIS TOY PRODUCES FLASHES THAT MAY TRIGGER EPILEPSY IN SENSITISED INDIVIDUALS.



K: 43-486-915 | T: 70-384-376


WARNING: CHOKING HAZARD
 SMALL PARTS. NOT FOR CHILDREN UNDER 3 YEARS.

WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (+ AND -). DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR AN EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.

WARNING: FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS, AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.

CITY TRACK POLICE

3+ YEARS









A		X8
B		X8
C		X260
D		X4
E		X1
F		X1
G		X1
H		X1

I		X1
J		X3
K		X2
L		X1
M		X2
N		X2
O		X2

A. SLOPE X 8 PIECES
 B. SLOPE COLUMN X 8 PIECES
 C. TRACK X 260 PIECES
 D. WHITE RAILWAY X 4 PIECES
 E. FORK X 1 PIECE
 F. POLICE STATION WALL X1 PIECE
 G. POLICE STATION BASE X 1 PIECE
 H. MOUNTAIN X 1 PIECE

I. PALM TREE X 1 PIECE
 J. INDICATOR X 3 PIECES
 K. CAR X 2 PIECES
 L. HELICOPTER X 1 PIECE
 M. WALL X 2 PIECES
 N. LOAD-BEARING COLUMN X 2 PIECES
 O. DOOR X 2 PIECES



WARNING: THIS TOY PRODUCES FLASHES THAT MAY TRIGGER EPILEPSY IN SENSITISED INDIVIDUALS.



K: 43-486-915 | T: 70-384-376

WARNING: CHOKING HAZARD
 SMALL PARTS. NOT FOR CHILDREN UNDER 3 YEARS.

WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (+ AND -). DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR AN EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.

WARNING: FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS, AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.