DRIFT RACER











How to pair

1. Turn on the vehicle first, then turn on the transmitter.


2. When the transmitter lights are flashing, pairing is in progress.

3. When lights stop flashing, pairing is complete.

4. If pairing is not complete within 8 seconds, please turn off both the vehicle and transmitter and re-start the pairing process.

5. When the pairing process is complete, whenever you switch the vehicle and transmitter on and off, it searches for the memorised code and will only lock onto the transmitter signal containing that code.

- 6. If you have more than two vehicles, please pair them one by one. When the second vehicle is pairing, always keep the first vehicle and transmitter on.
- 7. Please turn off both the vehicle and transmitter and re-start the pairing process if you are changing to another 2.4GHZ transmitter.



Always store batteries in a safe place.Keep out of reach of children.

· Always store batteries in a safe place. Keep out of reach of children. Ask adult for help when replacing the batteries.

①Use screwdriver to open the cover. ② Install batteries accurately in the battery compartment.

Charging:

1. Open battery cover and separate rechargeable battery from connector. 2. Connect USB charging cable with rechargeable battery first, then plug the large end of USB cable

- into a 5Vd.c. 2A charger (not supplied) or USB port only. The red LED light on USB charging cable will light up while charging.
- 3. After charging has finished, the LED light will turn off.

4. Disconnect USB charging cable from USB port and disconnect the rechargeable battery with USB charging cable.

Drifting function: Control the car with the white drift tyres in speed, then turn left or right for drifting function.

Warning: Choking hazard - Small parts. Not for children under 3 years.

Caution: The product has a rechargeable lithium-ion battery, only charge the product by plugging the large end of the USB cable into a 5Vd.c. 2A charger (not supplied) or USB port only. Only use the supplied cable for charging the product.

The battery charger used with the electric toy shall be regularly examined for damage to the supply cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until the damage has been repaired.

Non-rechargeable batteries are not to be recharged Different types of batteries or new and used batteries are not to be mixed

Batteries are to be inserted with the correct polarity (+ and –) Exhausted batteries are to be removed from the toy The supply terminals are not to be short-circuited The batteries should be charged under adult supervision.

