
尺寸: 230*150mm

Care Instructions:

Hand wash only. Wash with warm soapy water before first use.




Caution:


- > Keep out of reach of children.
- Breakable, handle with care.
- Do not move when full.
- > Not recommended for hot liquids or carbonated drinks.
- > Ensure the spout has been tightened as per the instructions below prior to using.
- \flat To allow a consistent flow of liquid from the dispenser, do not fully tighten the lid.

Assembly instructions

Step 1 with the spout upside down, hand tighten the nut clockwise on the inside of the drink dispenser.



Step 2 while holding the nut with one hand, turn the spout (through half a turn) clockwise with your other hand to tighten firmly.



Step 3 If the drink dispenser has any leaks, tighten the nut slightly to obtain a tighter seal.