

CAGE PENDANT LIGHT PD200

IMPORTANT SAFETY INSTRUCTIONS:


The following safety precaution should always be followed, to reduce the risk of electric shock, personal injury or fire. It is important to read all of these instructions carefully before using the product, and to save them for future reference or new users.

1. Carefully read these instructions when assembling and using this product before connecting to the electricity supply.
2. Use only the recommended bulb rating as detailed on the rating label and/ or lamp holder.
3. CAUTION: Electric shock hazard. "If the external flexible cable or cord of this luminaire is damaged it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard."
4. Never use a bulb that is rated more than the recommended wattage (refer to Bulb Type listed below).
5. Incandescent and halogen bulbs become very hot. DO NOT touch the bulb with your bare hands while the lamp is switching ON
6. Turn the power OFF and allow the bulb to cool down before replacing or cleaning.
7. Ensure the new bulb is secure in the lamp holder before turning on the electricity supply.

WARNING: TURN OFF MAINS POWER BEFORE INSTALLING BC PLUG ADAPTOR TO BATTEN HOLDER.

INSTALLATION

- 1) Install mounting tool (2) with ceiling hook (1) (not included) .
- 2) Connect BC plug adaptor (4) to installed batten holder (3).
- 3) Move batten cover so the top sits flush against the ceiling and tighten support anchor (5).
- 4) Connect the shade(6) to socket and fix with the socket ring(7).
- 5) Install the rated bulb - Max 60W B22 -GLS bulb (not included) or Max 42W B22 - Halogen bulb (not included) into the lamp holder.



Product Specification:

Rating Voltage:220-240V~ 50Hz

Bulb Required: 1xMax.60W B22 GLS bulb (Not included)

1xMax.42W B22 Halogen bulb (Not included)

DO NOT exceed the recommended light globe wattage

WARNING: Maximum load weight on pendent cord is 0.6Kg

**This is an Australian Standards requirement in the interest of your safety
For Indoor Use Only.**



12 Month Warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on **1800 124 125** (Australia) or **0800 945 995** (New Zealand) or alternatively, via email at **customer.satisfaction@kmart.com.au** for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.