



# ROD STORAGE STAND

## INSTRUCTIONS

A Phillips head  
Screw driver is  
needed to put this  
stand together.

**\* Caution:** This product includes  
small sharp parts. Please keep away  
from children until the rod storage  
stand is fully assembled

