

Warranty Card & manual - MIC ONLY

A6 105 x 148mm

Product Details

File name: 5060_MAN_IE_MIC_Only
 Artwork Proof Date: 14.03.18
 Proof Version: 1
 Number of artboards: 1

Printing Details

Print Colours: Single colour black

Do Not Print: **Dieline, Info**
 Flat Size: 105 x 148mm

ARTWORK SHOULD NOT BE AMENDED
 WITHOUT PRIOR AGREEMENT FROM CREST.
 ALL ARTWORK **MUST** BE APPROVED BY
 CREST PRIOR TO MASS PRODUCTION.
 THANK-YOU.

IF THERE ARE QUERIES ABOUT THIS ARTWORK PLEASE CONTACT:
 EMAIL: design@crest.com.au



Special Instructions

Please use 200gsm bright white coated paper

© The Crest Company 2018. All rights reserved.

anko

Thank you for choosing our Anko headphone/earphone. We hope you enjoy using it.

This headphone/earphone has an in-line music control function along with a call answering function that will work on most IOS and Android device

Overview:

1. Call answer and music control button
2. Microphone

*The position of the call answer button and microphone position are for illustration purposes only, the exact positions in different models may vary slightly.

How to use the In-line control functions:

A. Call answer

With the headphone/earphone connected to your device via the 3.5mm headphone socket.


Note: If you wish to make a call using the in-line microphone function the microphone will automatically activate whilst the headphone/earphone is connected to your device via the 3.5mm socket.

| Function | Operation |
|-------------|---|
| Call Answer | Short press the call answer/music control button to answer calls on your device |
| Hang Up | Short press the call answer/music control button to hang up your phone call |

B. Music Control Function

With the headphone/earphone connected to your device via the 3.5mm headphone socket.

| Function | Operation |
|-------------|---|
| Pause Music | Short press the call answer/music control button once to pause music Short press the call answer/music control button once to resume music |
| Skip Track | Short press the call answer/music control Forward button twice rapidly to skip track forward |
| Skip Track | Short press the call answer/music control Backwards button 3 times rapidly to skip track backwards |



WARNING › Do not dispose of unit in fire or water. › Never attempt to disassemble and reassemble. Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. Check with your local authority for recycle advice. › Keep your device and all accessories out of the reach of children and animals. Small parts may cause choking or serious injury if swallowed. › Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C). › Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device. › Do not allow your device to get wet—liquids can cause serious damage. Do not handle your device with wet hands.

12 Month Warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at Kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.