Size: 148(H) x 105(W)mm

Battery installation

- Make sure the toy is switched OFF (if applicable).
- Use a screwdriver (not included) to open the battery cover located from the back/bottom of the toy.
- Install the required batteries according to the diagram inside the battery compartment.
 Alkaline batteries are recommended.
- · Replace and secure the battery cover.
- Batteries must be installed and replaced by an adult.

Battery notice

- The use of rechargeable batteries is not recommended.
- Non-rechargeable batteries are not to be recharged.
- Do not mix old and new batteries (if applicable).
- Do not mix alkaline, standard (carbon zinc) or rechargeable batteries (if applicable).
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted according to the correct polarity (+ and -). Incorrect insertion
 can damage the unit, provoke fire or cause the batteries to explode.
- Rechargeable batteries are only to be charged under adult supervision (if removable).
- Rechargeable batteries are to be removed from the toy before being charged (if removable).
- Remove used batteries or rechargeables from the toy.
- Remove batteries when the toy is not to be used for a long period of time.
- · Do not throw batteries into a fire.
- Do not attempt to open ordinary or rechargeable batteries.
- The supply terminals are not to be short-circuited.
- Never leave button-cell batteries within reach of young children.
- Batteries are harmful if swallowed, so keep them away from young children.

Care and maintenance

- Keep the unit out of direct sunlight and away from any direct heat source.
- If the toy suddenly stops working, the voice becomes faint or the sound seems weak, the
 problem may be low battery power. If this is the case, install a new set of batteries before use.
 This sheet contains important information.

Please keep all information for future reference.

Uses 3 "AAA" size (UM4/LR03) batteries (included). Alkaline batteries are recommended. COLOUR AND DESIGN MAY VARY. PRODUCT SPECIFICATIONS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE



Item No. 42712688 Printed in China 0301–001080–NL–KM03–001

anko

Light & Sound Steering



