


# Wooden walker with Blocks

## Assembly instruction

keycode: 42735441



A  X2

B  X4

The toy is to be assembled by an adult. In unassembled state contain potentially hazardous points or small parts. So please keep out of baby reach.

Read all the instructions before assembly and use of the product.

Philips screwdriver (not included) is required for assembly.

Take care when unpacking and during assembly.

Dispose of all packing materials carefully after assembly.

Regularly check that all fittings remain tight. Tighten if required.

Inspect the product before assembly and periodically during use. Never use this product if there is any loose or missing fasteners, joints or broken parts.

Any additional or replacement parts should only be obtained from the manufacturer or distributor.

Never substitute parts.

Made in China