



# Floor Standing Tablet and Smartphone Stand

**Keycode: 42750512**  
**Instruction Manual**

## **Before first use:**

1. Unpack the device and check if all parts are there and undamaged. Should this not be the case, return the product to Kmart for replacement.
2. **Danger of suffocation!** Keep all packaging materials away from children.
3. Remove all protective foils and packaging material prior to use.

## **Safety Instructions:**

Please read the instruction manual before using this device and follow all the safety instructions to avoid damage caused by improper use.

- ▶ Keep the instruction manual for future reference. Should this device be given to a third party, then this instruction manual must also be handed over.
- ▶ Keep the device away from all hot surfaces and naked flames.
- ▶ Do not immerse the device in water or in other liquids.
- ▶ Do not use the device in wet conditions.
- ▶ Do not use the tripod in windy conditions or on an uneven surface.
- ▶ Do not use the device if it is damaged.
- ▶ This device is not a toy. Children should be supervised to ensure they do not play with the device.

## Parts:



## Assembly and Use:




01 Unscrew to nut to unfold the tripod to place it on a flat surface, tighten the screw again.



02 Install the telescopic rod to the desired length, tighten the screw.



03 Same as step 2.



04 Same as step 2.



05 Unscrew the screw nut behind the holder



06 Put the nut into the ball joint, aimed the rotation ball axis into the hole



07 Push the axis into the nut and secure the nut.



08 Assembly completed. Mount the device on the floor stand, ready to use.



09 The additional smartphone mount assembly method is same as tablet mount.