

STUNT SHARK


3+ YEARS

Installing batteries in the remote control:

- 1 - Open the battery compartment.
- 2 - Insert 2 x 1.5V AAA batteries with the correct + and - polarities.
- 3 - Close the cover.



Installing the vehicle battery:



How to use:

1. Turn on the vehicle and then turn on the remote control.
2. When the vehicle is functioning, this means they have matched.

Start:



1. How to move forwards or backwards:
Push both levers up, the vehicle will move forwards. (see Diagram 1)
Push both levers down, the vehicle will move backwards. (see Diagram 2)




2. How to swerve left or right:
Push the right lever up, the head will swerve left. (see Diagram 3)
Push the left lever up, the head will swerve right. (see Diagram 4)



3. How to rotate 360 degrees:
Push the left lever up and right lever down simultaneously, the vehicle will rotate clockwise. (see Diagram 7)
Push the left lever down and right lever up simultaneously, the vehicle will rotate anticlockwise. (see Diagram 8)



4. How to flip up:
When the vehicle is tipped-over to left, push the left lever up (down) for a few seconds and then push it down (up) and hold on until the vehicle flips up. (see Diagram 9)
When the vehicle is tipped-over to right, push the right lever up (down) for a few seconds and then push it down (up) and hold on until the vehicle flips up. (see Diagram 10)



Attention: Use stunt shark on a hard, smooth floor for better flip up function performance.

WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (+ and -) DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION. RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.

WARNING: FOR SAFETY REASONS REMOVE ALL TAGS, LABELS AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.

WARNING: CHOKING HAZARD SMALL PARTS. NOT FOR CHILDREN UNDER 3 YEARS.

PRODUCT MAY VARY SLIGHTLY FROM IMAGE SHOWN. PLEASE KEEP THE PACKAGING FOR FUTURE REFERENCE. PERFORMANCE TIPS: DO NOT DRIVE THE VEHICLE THROUGH WATER. DO NOT DRIVE THE VEHICLE INTO ANY HARD OBJECT.

MADE IN CHINA
© KIMART AUSTRALIA LIMITED.
KIMART AUSTRALIA - 888 SPRINGVALE ROAD, MULGRAVE, VICTORIA 3170 AUSTRALIA.
KIMART NEW ZEALAND - REGIONAL OFFICE
C/O KIMART PARATITOE STORE,
HUNTERS PLAZA, GREAT SOUTH ROAD,
PAPATOETOE, AUCKLAND, NEW ZEALAND.



Z516

27MHz

Keycode: 4275894