

Deluxe Gazebo


KC 42768531

Parts

01



A. Tube Frame x 1



B. Cover x 1



A. Pegs x 8



B. Bag x 1

WARNING & CARE INSTRUCTION

02

WARNING:

- KEEP ALL THE FLAMES AND HEAT SOURCES AWAY FROM THIS PRODUCT.
- THIS GAZEBO IS NOT A PERMANENT STRUCTURE.
- DON'T SET UP OR CONTINUE TO USE IN RAIN, WIND, OR IN ADVERSE WEATHER CONDITIONS.
- DON'T USE BBQ'S OR BUILD FIRES UNDER THE CANOP.
- ENSURE GAZEBO SECURED TO THE GROUND WITH PEGS.
- CAREFUL NOT TO GET FINGERS CAUGHT WHEN FOLDING/UNFOLDING THIS PRODUCT.

CARE INSTRUCTION:

- WIPE CLEAN WITH A DAMP CLOTH.
- DO NOT USE ABRASIVE MATERIALS AND SOLVENTS.
- STORE IN A CLEAN, DRY AREA WHEN NOT IN USE, AND ENSURE THAT THE GAZEBO IS COMPLETELY DRY BEFORE STORING.
- HANDLE WITH CARE WHEN CONNECTING POLES TOGETHER.
- LONG EXPOSURE TO THE SUN MAY RESULT IN SOME LOSS OF COLOUR.

Deluxe Gazebo


KC 42768531

Assembly Instruction

03


Step 1

Unfold the metal tube frame to about 2 x 2 m.




Step 2

Take the Cover on the top of metal tube frame, then fix the cover to the metal tube frame at 4 corners by velcro, unfold the metal tube frame as large as possible till lock the tube by button.



Step 3

Extend the leg from the bottom to adjust the height of the 4 legs, then tie all the belt to metal tube.
Note: 8 pcs pegs can be inserted in the ground to fix the legs.
3 positions height is available according to your request.



Made in China