

SAFETY INFORMATION


⚠️ WARNING:

- Protective equipment should be worn such as a helmet, gloves, knee-pads and elbow-pads.
- Always wear fully enclosed shoes.
- Do not use scooter at night.
- Do not use on wet surfaces, uneven or unpaved road.
- It is not recommended the scooter be used on steep slopes at high speed.
- Avoid sharp bumps, drainage gullies and sudden surface changes.
- This scooter is not designed for off-road use or stunting.
- Never ride with more than one person on the scooter.
- Always follow local traffic laws.
- Always check the brakes before riding.
- Adult assembly required.
- Brake will get hot from continuous use, do not touch after braking.
- Read all information supplied by the manufacturer before riding.
- Recommended for children age 5 and up.

NOT FOR CHILDREN WITH A BODY MASS OF MORE THAN 30KGS. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY CAUSE SERIOUS INJURY

- Check and secure all fasteners before every ride.
- Ensure the clamp is locked correctly into position before every ride.
- **Wheels and Bearings:** Periodically check wheels and bearings for wear and tear and correct axle tightness.
- Replace worn and broken parts immediately.
- A reminder that the toy shall be used with caution, since skills are required to avoid falls or collisions causing injury to the user or third parties.
- The dangers of using it on public highways or public roads.

Thanks for your purchase this product. If any parts are missing or damaged, please contact one of our Customer Service Representatives by phone on **1800-632-792 (Australia)** or **0800-623-792 (New Zealand)** via email at spares@hunterleisure.com.au visit www.momentumsservicesco.com Hunter Leisure Pty Ltd 94 Kellor Park Drive Tullamarine, 3043, Victoria, Australia



⚠️ WARNING:
Failure to correctly install and tighten clamp may cause the rider to lose control and fall from the scooter. If you are unsure, please seek assistance by an experienced bicycle mechanic.
No modifications should be made to the scooter. The supplier will not be liable for any damage or injury that may occur with a modified product.


⚠️ WARNING:
THIS MANUAL CONTAINS IMPORTANT SAFETY, ASSEMBLY AND MAINTENANCE INFORMATION. Keep this manual for future reference.
ASSEMBLY MUST BE COMPLETED IN ACCORDANCE WITH THE INSTRUCTIONS AND WARNINGS PROVIDED IN THIS MANUAL. If you do not have the required tools, please refer to the assembly instructions for more information.
FAILURE TO FOLLOW THESE INSTRUCTIONS MAY CAUSE SERIOUS INJURY.



INLINE SCOOTER OWNERS MANUAL

SCOOTER MAINTENANCE:
Regularly maintaining your scooter will provide years of scooter-riding fun. To keep your scooter in good working order, do the following:
1. Before every ride, check and verify that the scooter is properly set up and locked.
2. After riding, clean your scooter with a dry cloth to remove dirt and grime.
WEEKLY SERVICE:
Apply a few drops of general purpose oil (available at your local hardware store) to the sides of each wheel axle. Verify that the axle screw are tight.
PLEASE BE PERFORMED BY YOU AND ADULT SUPERVISORS:
Apply a few drops of general purpose oil (available at your local hardware store) to the sides of each wheel axle. Verify that the axle screw are tight.

MAINTENANCE



RIDING YOUR SCOOTER

1. Place one foot on the footboard of the scooter and use your other foot to propel the scooter.
2. To stop the scooter, apply the brake by stepping on the rear brake. We recommend that you practice applying the brake at various speeds and in an open area free from obstructions.