

# anko

## Specification:

45x35mm Amorphous Solar Panel  
 1pc AA Ni-Cd rechargeable battery 1.2V, 200mAh  
 Multi Colour LED (Reindeer String Lights)  
 Multi Colour LED (Strawberry String Lights)  
 Warm white LED (Star String Lights)  
 Cool White LED (Snowflake String Lights)

## IMPORTANT:

- Charge battery for at least 8 hours before first use.
- The solar light panel MUST be placed in a well-lit location for maximum sunlight. Anything that shades the panel will affect the brightness and lighting duration
- Put the switch on the "OFF" position when not in use or in storage.
- Use a damp cloth to clean it when there is a buildup of dust and/or dirt on the surface of the solar panel.

## Battery Replacement

The battery is non-replaceable. DO NOT attempt to replace it.

## Bulb Changing

The light set is constructed with non-replaceable bulbs. DO NOT attempt to replace any of the bulbs in the light set.

WARNING: FOR DECORATION ONLY. THIS IS NOT A TOY. DO NOT ALLOW CHILDREN TO PLAY WITH AND HANDLE LIGHT SETS.

## SOLAR POWERED 24 LED STRING LIGHTS

### Instructions:

- › Assemble the solar panel as shown in the picture.  
 A-Solar Panel B-Plastic Spike
- › Attach part B on to the back of solar panel A by pressing firmly.
- › Turn the ON/OFF switch to "ON" position. You will only need to do this once, as the solar panel will turn the lights on and off automatically.
- › Place entire unit in a sunny position where there is soft ground to enable the spike to be pushed in easily



Keycode: 42779605