
anko 40cm pedestal fan

Please refer to the Instruction Manual for more details and images of the assembly procedure.

STEP 1: INSTALL SAFETY GRILLE AND FAN BLADE



First take the **Motor Assembly** and unscrew the **Locking Nut** (anticlockwise) and remove the protective plastic sleeve from the motor spindle shaft.



Place the **Back Safety Grille** into position ensuring the safety grille fits onto the locating lugs. (*Note: The handle on the back of the grille will be at the top if this is done correctly.)




Fix the back safety grille into position by screwing the Locking Nut (clockwise) tightly by hand. (Note: Do not over tighten the locking nut.)




Place the **Fan Blade** onto the motor spindle.



Fix the blade into place by gently hand tightening the **Spinner Nut** (anticlockwise) onto the end of the motor spindle.



Place the **Front Safety Grille** into position and secure it by closing the clips over the outer rim.




Using the **Small Nut and Bolt**, fasten the two grilles together.


STEP 2: ASSEMBLE PEDESTAL STAND, BASE AND HEAD



Assemble the **Cross Base** and remove the 4 fasteners.



Fix the **Pole** on the cross base and refit the 4 fasteners and tighten.



Drop the **Base Cover** over the cross base.




Loosen the **Height Adjustable Locking Ring** and extend the support pole to your desired height.

(Note: The metal pole may have sunk into the metal body occasionally. Simply unscrew the locking ring, tip the pole up side down and you will find it.)



Retighten the Height Adjustable Locking Ring to prevent slipping.



Take the fan assembly and place it onto the pole and tighten the **Pole Screw** by hand.

If you are missing a part or having troubles when assembling the fan, please feel free to call our friendly customer service team on our toll free number: 1300 105 888 or via email info@hegroup.com.au. We will be glad to assist you.